

How to identify if your battery has been recalled.

Tool Needed: Phillips Head Screwdriver



INSTRUCTIONS FOR:

CRAZY KICKER XS

Item 53012

- 1. Release metal latch between decoy body and floating base
- 2. Lift decoy body to reveal rubber battery compartment seal
- 3. Using a phillips head screwdriver, remove two screws securing rubber battery compartment seal
- 4. Peel back rubbery battery compartment seal
- 5. Remove battery and check the label for make and model information. If the TOP line on the battery sticker reads "Sun Lilon Battery," it <u>IS</u> part of the recall. If your battery says "Sun Li-lon battery" on the top line, your next step is to complete our recall form at: www.higdonoutdoors.com/recall

Please Note: ANYTHING other than these exact words on the top line means your battery is **NOT** part of the recall.

Item	Description
53012	XS Crazy Kicker, Mallard Drake 12V (with timer)
99117	XS Battery 12v 2.5Ah Li-ion, 2021 (for all XS motion)









