

HIGDON OUTDOORS

How to identify if your battery has been recalled.

INSTRUCTIONS FOR:

FLOATING FLASHER XS

Item 53072

SPLASHING FLASHER XS

Item 53077

1. Twist the decoy body counter clockwise and pull up to remove from floating base
2. Open hook & loop tabs to free the battery
3. Remove battery and check the label for make and model information. If the **TOP** line on the battery sticker reads “Sun Li-Ion Battery,” it ***IS*** part of the recall. If your battery says “Sun Li-Ion battery” on the top line, your next step is to complete our recall form at: www.higdonoutdoors.com/recall

Please Note: ANYTHING other than these exact words on the top line means your battery is **NOT** part of the recall.



Item	Description
53072	XS Floating Flasher, Mallard Drake 12V
53077	XS Splashing-Flasher, Mallard Drake 12V (with timer)
99117	XS Battery 12v 2.5Ah Li-ion, 2021 (for all XS motion)