

How to identify if your battery has been recalled.

Tool Needed: Phillips Head Screwdriver



INSTRUCTIONS FOR:

PULSATOR XS

Items 50033, 50044, 50534, 50053, 50054, 50734, 54034

- 1. Pinch tabs and remove bilge pump
- 2. Using a phillips head screw driver, remove four screws, freeing the bilge pump assembly.
- 3. Remove waterproof battery box
- 4. Release tabs to open battery box and remove battery.
- 5. Remove battery and check the label for make and model information. If the TOP line on the battery sticker reads "Sun Li-lon Battery," it <u>IS</u> part of the recall. If your battery says "Sun Li-lon battery" on the top line, your next step is to complete our recall form at: www.higdonoutdoors.com/recall

Please Note: ANYTHING other than these exact words on the top line means your battery is **NOT** part of the recall.

Item	Description
50033	XS Pulsator, Mallard Drake 12V
50044	XS Pulsator, Mallard Hen 12V
50534	XS Pulsator, Pintail 12V
50734	XS Pulsator, Canada Goose 12V
50053	XS Pulsator Mallard Combo Pack Drake/Drake
50054	XS Pulsator Mallard Combo Pack Drake/Hen
54034	XS Pulsator & XS Bttlship Swmmr, Both Mllrd Drake 12V combo
99117	XS Battery 12v 2.5Ah Li-ion, 2021 (for all XS motion)









