



# FITTING THE ATLAS 4 HOIST

If you're considering purchasing an Atlas 4 Car Boot Hoist then you will need to assess the boot type in your car.

The hoist is fitted by forming tension between the front/back and sides of the car boot walls.

Therefore a lot of modern styles with a flat boot will not be able to support the hoist as there is no supporting wall available.



Car Boot With Lip ✓



Car Boot Without Lip ✗



← The feet of the hoist will position in the car like shown here. This is why having the 4 walls in your car boot is necessary for fitting the Atlas 4 Car Boot hoist in.