

BBQ Pizza Box

Convert your charcoal or gas grill into a pizza oven



CAREFULLY READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE.

Read the instructions for use carefully, especially the safety instructions, before using the Pizza Box. Failure to comply with these instructions for use can lead to serious injuries or damage to the Pizza Box.

SAFETY - INTENDED USE

The Pizza Box is only intended for private use and is not suitable for commercial use. Use the Pizza Box only as described in these instructions for use. Any other use is considered to be misuse and can lead to property damage or personal injuries. The Pizza Box is not a toy. The manufacturer does not accept any liability for damage caused due to misuse or incorrect use.

SAFETY INSTRUCTIONS

WARNING - FIRE RISK

- ATTENTION! Place your grill on a level, horizontal, secure, heat-resistant surface before you fit the Pizza Box.
- ATTENTION! The Pizza Box becomes very hot and may not be moved during operation.
- Always have a fire extinguisher and a first-aid box ready to hand, so that you are prepared in case of an accident or fire.
- Do not use in enclosed spaces or rooms!
- Do not use under areas covered with a roof!
- Only use the Pizza Box at a safe distance (at least 1.5 m) from flammable material e.g. furniture and wooden buildings.
- When handling the Pizza Box, wear appropriate protective gloves.
- Only use grill utensils with a long, heat-resistant handle to put on and to turn the food.
- Do not clean the Pizza Box until it has completely cooled.
- Check the condition of the Pizza Box regularly. Damage to the Pizza Box can cause fires and injuries!

WARNING - RISK OF BURNS AND ACCIDENTS

The Pizza Box is not intended to be used by persons (including children) with limited physical, sensory or mental abilities or lack of experience and/or lack of knowledge.

- ATTENTION! Keep away from pets and children!
- Children should be warned by their parents of the danger of fire and the heat of burning and hot objects.

• Point out the dangers to this group of people and have this group of people supervised by a person responsible for their safety.

• Any changes to the Pizza Box constitute a large safety risk and are prohibited.

• In case of damage, repairs or other problems, contact our service department. Do not carry out any unauthorised interventions yourself.

• Do not let children play with the packaging film or other small parts. Risk of suffocation!

WARNING - RISK OF BURNS

The Pizza Box and the grill become very hot during use. Any contact with them can lead to serious burns.

- Do not leave children and pets unsupervised while the Pizza Box is in operation.
- Do not wear clothing with wide sleeves.

• Pay attention at all times and always take care of what you are doing. Do not use the Pizza Box if you lack concentration, are tired, or are under the influence of drugs, alcohol or medication. A short moment of inattention can lead to serious injuries.

DANGER - RISK OF POISONING

Do not operate the Pizza Box in enclosed and/or habitable spaces, e.g. in buildings, tents, caravans, motorhomes or boats. Risk to life due to carbon monoxide poisoning. Only use the Pizza Box outdoors!

WARNING - RISK OF INJURY

The Pizza Box can have sharp edges. Handle the Pizza Box carefully, so that you avoid accidents or injuries. Wear appropriate protective gloves.

NOTE - RISK OF DAMAGE

Check the condition of the Pizza Box before each use. The damaged Pizza Box may no longer be used.

POC230 | PR4771

NOTE - RISK OF DAMAGE

If you open the packaging carelessly with a sharp knife or other pointed objects, the Pizza Box can quickly become damaged. Open the packaging very carefully.

- 1. Remove the Pizza Box and the pizza stone from the packaging.
- 2. Check for damages. If found, do not use the Pizza Box. Use the phone number below to contact our customer service.

RISK OF DAMAGE

Incorrect storage can lead to rust. If you are not going to use the Pizza Box for a lengthy time, store the cleaned and dry Pizza Box in a dry room protected from the weather. If necessary, store the pizza stone separately.

OPERATION

• Unpack the Pizza Box carefully. Attention! The pizza stone is breakable.

• Place the pizza stone in the Pizza Box. Do not wet the pizza stone with water or soak it before use. Heat it up properly before use.

• The Pizza Box can be used both on a gas-fired grill and on a charcoal grill.

• If using on a gas-fired grill, place the Pizza Box on the grill first before igniting the grill. If using on a charcoal grill, ignite the grill first before placing the Pizza Box on it.

• If operating with a gas-fired grill, please adjust the flame setting according to the required temperature at the thermometer of the box.

• Only use with grills that have a sufficiently large cooking grate. A minimum diameter of approx. 53 cm for round grills, a minimum size of approx. 50 x 45 cm for rectangular grills

• To place/remove the pizza in/out of the Pizza Box and to remove the pizza stone, please insert the pizza peel carefully, to avoid damage.

• To achieve an optimum result, please never keep the temperature continuously in the upper "HOT" range, but in the "IDEAL" range.

• Please note that cooking times can vary depending on the grill.

TRANSPORT WARNING

The Pizza Box may only be transported if it has completely cooled!

CLEANING AND STORAGE CAUTION - RISK OF BURNS

You can burn yourself if you clean the Pizza Box before all the parts have completely cooled. Allow the Pizza Box to cool completely before you clean it or wear protective gloves.

RISK OF DAMAGE

Improper handling of the Pizza Box can lead to damage.

• Do not use aggressive cleaning agents, steel brushes, abrasives or other hard objects, which could scratch the surface of the housing and the pizza stone.

• Clean the parts by hand using standard washing-up liquid. In case of heavy or burnt-in soiling, additionally use special grease-dissolving kitchen cleaners (follow the instructions of the respective manufacturer!).



www.lenoxx.com.au

1300 666 848



