



Model: SL1843
Batch: PR4558
Instruction Manual

Please read and retain these instructions for future reference.

Battery Precautions:

- If battery contents are leaking, discontinue use and discard.

Battery Disposal:

Batteries are not replaceable. Please dispose of batteries according to the local laws and regulations of your region. Some batteries may be recycled and may be accepted for disposal at your local recycling center.

Product Contents:

- 3 Solar power lights
- 6 Small screws
- 3 Double-sided adhesive tapes
- 1.2 V, 150mAh AAA rechargeable battery

Charging the Solar Deck Lights:

- Remove the plastic tab from each solar deck light by pulling on the tab.
- The rechargeable battery must charge for approx. 8 – 12 hours in direct sunlight prior to use.
- To maximize the charge time, position the unit in a location with plenty of unobstructed sunlight and away from the shade.
- Ensure that the solar panel is always clean in order to obtain the greatest possible collection of light. Occasionally, clean the solar panel with a damp cloth. Important: never use solvents or abrasive cleaning agents.
- Note: Overcast days and shade may affect the duration of light and brightness.

Installation:

- Place and hold the solar deck light with the solar panel facing upward over the top edge of the deck, handrail, etc.
- Use the included screws or double-sided adhesive tape to mount.
- The solar deck lights will turn on automatically at dusk and will operate continuously for approx. 6 hours when fully charged.
- Repeat the same installation process for each solar deck light.

LENOXX

www.lenoxx.com.au

 1300 666 848

 LenoxxElectronics

 LenoxxElectronics

 @LenoxxAustralia