


# LENOXX™

## Wireless Charging Desktop Mat

WCDM15 | PR4883

### OVERVIEW



1. USB-C port
2. Indicator light
3. Wireless earbuds charging area
4. Wireless phone charging area
5. Reversible desk mat

# CONNECT

1. Connect the included USB charging cable to the USB-C port and connect the other end to an external power adapter (QC2.0/3.0 18W or higher power adapter) .
2. The blue light on top of the charging panel indicates it's properly connected and ready for charging.

# ATTENTION

1. This device is designed for indoor use only.
2. Do not expose the charging pad to direct sunlight or high-temperature conditions.
3. Keep away from water and any other liquid.
4. Disconnect the USB cable before cleaning the charging mat.
5. If the product becomes damaged, do not use it as this could pose a risk of causing damage to connected devices.

# LENOXX™

[www.lenoxx.com.au](http://www.lenoxx.com.au)



1300 666 848



LenoxxElectronics



LenoxxElectronics