

## **80 Series Parts Manual**




Assembly No.	Description	Option	Sellable
68-2694	Wide Stile E Rail Assembly*		Yes
68-2695	Wide Stile F Rail Assembly*	]	Yes
68-2696	Wide Stile G Rail Assembly*	]	Yes
68-2697	Wide Stile J Rail Assembly*	Standard	Yes
68-2716	Narrow Stile E Rail Assembly*	Rails	Yes
68-2717	Narrow Stile F Rail Assembly*		Yes
68-2718	Narrow Stile G Rail Assembly*		Yes
68-2719	Narrow Stile J Rail Assembly*		Yes
68-7520	Wide Stile E Rail Assembly*		Yes
68-7521	Wide Stile F Rail Assembly*		Yes
68-7522	Wide Stile G Rail Assembly*	Standard	Yes
68-7523	Wide Stile J Rail Assembly*	Rails	Yes
68-8001	Narrow Stile E Rail Assembly*		Yes
68-8097	Narrow Stile F Rail Assembly*	(5CH-)	Yes
68-8289	Narrow Stile G Rail Assembly*	]	Yes
68-8193	Narrow Stile J Rail Assembly*		Yes

Item	Assy No.	Part No.	Description	Qty	Sellable
1		68-0550	Mounting Rail Insert Wide(E)*	1	Yes
		68-0549	Mounting Rail Insert Wide(F)*		Yes
		68-0554	Mounting Rail Insert Wide(J)*		Yes
		68-0551	Mounting Rail Insert Wide(G)*		Yes
		68-1375	Mounting Rail Insert Narrow(E, F)*		Yes
		68-0553	Mounting Rail Insert Narrow(J)*		Yes
		68-0552	Mounting Rail Insert Narrow(G)*		Yes
2		01-1236	#6-32x3/8 PH FL U'Cut	4	Yes
	See Table	68-0950	Mounting Rail, E Wide*		Yes
		68-0952	Mounting Rail, F Wide*		Yes
		68-0948	Mounting Rail, J Wide*		Yes
3		68-0949	Mounting Rail, G Wide*	1	Yes
) 3		68-0958	Mounting Rail, E Narrow*	]	Yes
		68-0955	Mounting Rail, F Narrow*		Yes
		68-0956	Mounting Rail, J Narrow*		Yes
		68-0957	Mounting Rail, G Narrow*		Yes
4	Above	68-0943	Bracket	2	Yes
5		68-3609	Connecting Arm Assembly	2	Yes
6		01-4466	Machine Screw SEMS <sup>1</sup>	1	Yes
7		68-0582	Lockdown Cam <sup>1</sup>	1	Yes
8		01-0610	Wave Spring Washer <sup>1</sup>	1	Yes
9		68-0236	Spring, Rail Arm	2	Yes
9	9	68-1832	Spring, Rail Arm (5CH-)	2	Yes
10		68-0945	Pivot Pin	2	Yes
11		01-0098	Retaining Ring	2	Yes
12		68-0229	Pivot Pin Push Rail*	2	Yes
13		68-0583	Lockdown Button <sup>1</sup>	1	Yes
14		809	Touch Pad Assembly	1	Yes
15		68-0615	Push Rail, E*	1	Yes
		68-0618	Push Rail, F*		Yes
		68-0616	Push Rail, J*		Yes
		68-0617	Push Rail, G*		Yes

\*Specify Finish

1. Do not use on any 12- Rail Assembly





Assembly 68-2695 Shown Above

91