

# User instructions

The safe is locked when leaving the factory.

## Using an override key to unlock your safe

- 1 Remove the lock cover.
- 2 Insert the key into the lock with the small lugs uppermost.
- 3 Press the key in and turn to the LEFT past slight resistance, approximately one EIGHTH of a turn until it stops. Holding the key against the stop, turn the handle to the RIGHT to unlock the door.

## Activating the digital lock

- 4 Unclip the battery cover inside the door and insert the four batteries provided, observing correct polarity. The digital lock will beep once to indicate power is on.

**We recommend keeping the door OPEN for the following steps. Turn the handle to the LEFT to extend the bolts.**

Note that it is not necessary to use a code to LOCK the safe - simply turning the handle to the LEFT will engage the bolts.

## Setting your own digital code

- 5 Choose a memorable code with 3 - 8 digits, letters or numbers or a combination of both. Locate the RESET BUTTON inside the door. Remove the cover and press the button ONCE. **When the button is pressed, the YELLOW light illuminates and you have approximately 15 SECONDS to set your code.**

- 6 Apply your code via the keypad. Successful setting will be confirmed by one beep and the YELLOW light will switch off. **Test the lock immediately** with your new code - after **5 SECONDS** the GREEN light will switch off and the digital lock will time out. Save a reminder of your digital code, replace the battery cover and the lock cover and keep the override keys in a safe place.

## Important

- If setting a new code is unsuccessful, the lock will beep three times and the yellow light will flash. Wait 20 seconds before trying again.
- When an incorrect code is entered more than 3 times, the lock will time out and beep for 20 seconds. Wait 30 seconds before trying again.
- If, when opening the safe, the red light is on, replace the 4 x AA batteries. Use an override key to unlock the safe (see instructions 1 - 3 above) if the batteries fail.
- We recommend securing your safe via the pre-drilled holes. Expanding fixings (for masonry) are provided.

