





YORK ASPIRE 420 HOME GYM ITEM #43420 OWNER'S MANUAL PLEASE READ THIS INSTRUCTION MANUAL BEFORE YOU BEGIN ASSEMBLY. Great care has been taken to design these instructions and following them will help you with quicker assembly and minimize the risk of injury.

It is important that you keep these instructions for future reference.

This list is not exhaustive - You are responsible for your own safety!

- · Assemble the product on a level surface
- · You will need at least one person to help you assemble this unit.
- Always use the product on a level surface, ensure that the product is stable before use.
- Always ensure that the equipment has adequate space on each side and front (the back can be near to a wall).
- Replace defective components immediately, and/or keep the equipment out of use until it is repaired.
- Use only the adjustment settings as described in the instructions. Always use the correct adjustment pin and/or locking devices.
- Always check that any pins / fixings are tight and secure before use and / or after adjustment.
- · Never leave any adjustment devices projecting from the product.
- Always consult your doctor before undertaking any exercise program.
- · Always wear suitable clothing and footwear e.g. tracksuit / shorts / training shoes
- · Remove all personal jewelry before exercising.
- Ensure you warm-up well before using the equipment as this will help to prevent muscle strain.
- After eating, allow 1-2 hours before exercising as this will help to prevent muscle strain.
- · Injuries to health may result from incorrect or excessive training.
- Never overload the equipment the maximum user load is displayed in these instructions and on the product label.
- We recommend that you do not lift weights alone. There should be somebody there to assist you.
- Never use the equipment in any other manner other than the ways explained in these instructions and/or any wallchart supplied.
- Parents and others in charge of children should be aware of their responsibility, because the natural play instinct and the fondness of experimenting of children can lead to situations and behavior for which the training equipment is not intended.
- If children are allowed to use the equipment, their mental and physical development and above all their temperament should be taken into account. They should be controlled and instructed in the correct use of the equipment.
- The equipment is under no circumstances suitable as a children's toy.
- Children should not be allowed on, or around the equipment especially when it is not in use.
- This product has been tested for use in a home environment and is warranted for In Home, personal, family or household use.
- Due to our continuous policy of product development, York Fitness reserves the right to change specifications without notice.

CAUTION! The instructions must be followed carefully in the assembly, use and maintenance of your equipment. The warranty does not cover damage due to negligence of the assembly, adjustment and maintenance instructions described herein.

THIS PRODUCT IS NOT SUITABLE FOR THERAPEUTIC PURPOSES.

100KG USER WEIGHT 150KG TRAINING WEIGHT

TOOLS AND CONSUMABLES


- 2 x 14-17mm double ended spanner
- 2 x 17-19mm double ended spanner
- 1 x Wrench 5mm
- · Pliers should not be used!



CUSTOMER SUPPORT

Should you require any assistance regarding this product please gather the following information and then contact us using the details below:

- · Serial No. This can be found on the sticker below, located as indicated.
- Original purchase date
- · Place of purchase
- · Information about the place and conditions of use
- · Precise description of the issue / defect



IMPORTANT!! - Please retain your sales receipt, York Fitness Customer Care may request proof of purchase to validate eligibility for warranty service. Warranty cover starts from the date shown on the proof of purchase.

CARE & MAINTENANCE

- Always place the equipment in a dry environment.
- Use a warm, damp cloth to keep the product clean.
- The safety level of the equipment can be maintained only if it is regularly examined for damage and wear at the start of every use. This includes any nuts, bolts, moving parts, bushes etc.
- Always replace damaged / worn components with original parts from the manufacturer.

PREPARE YOUR WORK AREA - It is important you assemble the product in a clean and uncluttered space.

WORK WITH A FRIEND - We recommend you have someone assist you with the assembly as some of the components are quite heavy.

UNPACK THE CARTON - Remvoe all the parts and lay them out on the floor.

CHECK TO MAKE SURE YOU HAVE ALL PART, NUTS, BOLTS... ETC, BEFORE YOU START ASSEMBLY.

IF YOU ARE MISSING ANY PARTS AND THE BOX WAS UN-OPENED WHEN YOU LEFT THE STORE, PLEASE CONTACT YORK COSTUMER SERVICE (CONTACT INFORMATION ON THE BACK OF THE MANUAL).




EXPLODED DRAWING / PART LIST

REF.	DESCRIPTION	QTY
1	Rear Base Frame	1
2	Front Base Frame	1
3	Weight Guide Tube	2
4	Front Support Frame	1
5	Selector Shaft	1
6	Leg Extension Frame	1
7	Seat Base Frame	1
8	Support Frame	1
9	Upper Cross Beam	1
10	Press Bar	1
11	Left Butterfly Arm	1
12	Right Butterfly Arm	1
13	Pulley H	1
14	Single Pulley Block	2
15	Reverse U	1
16	Lat Bar	1
17	Foam Tube	2
18	Handle Tube	2
19	Tobacco-pipe	1
20	Pothook	2
21	Weight Selector Pin	1
22	Rubber Ring	2
23	Top Weight Plate	1
24	Weight Plate (10LB)	9
25	Wrench	1
26	Big Washer	1
27	Selector Shaft Pin	1
28	Seat Cushion	1
29	Back Cushion	1
30	Leg Foam Roller	4
31	Arm Foam Roller	2
32	Pulley (3.5")	12
33	Pulley Cover	2
34	Plum Blossom Nut	1


REF.	DESCRIPTION	QTY
35	Upper Cable (Length: 2870 mm)	1
36	Lower Cable (Length: 3400 mm)	1
37	Butterfly Cable (Length: 2750 mm)	1
38	Oil Bushing (Small)	2
39	Oil Bushing (Big)	4
40	Select Shaft End Cap	1
41	Countersink Head Bolt (M8x25mm)	4
42	Chain (Length: 265 mm)	1
43	Bumper	1
44	Selector Shaft Bushing	1
45	Round Cap (ø25mm)	1
46	Handle Grip	6
47	Square End Cap (ø38mm)	8
48	Square End Cap (ø45mm)	2
49	Square Cap (ø38mm)	3
50	Square End Cap (ø20x40mm)	2
51	Middle-empty Cap (ø38 x ø26)	2
52	Round End Cap (ø25mm)	4
54	Hex Bolt (M12x120mm)	1
55	Hex Bolt (M10x65mm)	2
56	Hex Bolt (M10x60mm)	11
57	Hex Bolt (M10x45mm)	12
58	Hex Bolt (M8x20mm)	2
59	Hex Bolt (M8x50mm)	2
60	Hex Bolt (M8x40mm)	2
61	Hex Bolt (M8x25mm)	1
62	Hex Bolt (M8x15mm)	4
63	Washer (M12)	4
64	Washer (M10)	50
65	Washer (M8)	14
66	Nylock Nut (M12)	3
67	Nylock Nut (M10)	25
68	Nylock Nut (M8)	3








IF YOU SUSPECT YOU MAY HAVE SOME PARTS MISSING, PLEASE CONTACT US BEFORE GOING BACK TO YOUR RETAILER. REFER TO THE CUSTOMER SUPPORT SECTION FOR CONTACT DETAILS.











PARTS





WARNING: VERY IMPORTANT INFORMATION


IT IS VERY IMPORTANT TO ENSURE THAT THERE ARE ENOUGH THREADS ENGAGED INTO THE TOP OF THE SELECTOR STEM




Ensure that the threads are engaged accordingly by measuring the length of the remaining threads.



ASPIRE










M12x120mm Hex Bolt x 1PC () M8x20mm Hex Bolt x 2PCS (pre-installed) (pre-installed) M8x40mm Hex Bolt x 1PC () M12 Washer x 4PCS (pre-installed 2pcs) M8 Washer x 4PCS (pre-installed 2pcs) M12 Nylock Nut x 3PCS (pre-installed 2pcs) M8 Nylock Nut x 1PC 🔘 P do. (pre-installed)

- 56 M10x60mm Hex Bolt x 5PCS
- 59 M8x50mm Hex Bolt x 2PCS
- 62 M8x16mm Hex Bolt x 4PCS 🕽
- 64 M10 Washer x 10PCS 🔘
- 65 M8 Washer x 6PCS 🔘
- 67 M10 Nylock Nut x 5PCS 🔘














- 32 Pulley (3.5") x 3PCS
- 37 Butterly Cable (2750mm) x 1PC @ →
- 57 M10x45mm Hex Bolt x 3PCS
- 64 M10 Washer x 6PCS (0)
- 67 M10 Nylock Nut x 3PCS





8

- 32 Pulley (3.5") x 5PCS (1pc pre-installed)
 33 Pulley Cover x 2PCS (pre-installed)
- 36 Lower Cable (3400mm) x 1PC @=-//----@
- 57 M10x45mm Hex Bolt x 5PCS (1pc pre-installed)
- 60 M8x40mm Hex Bolt x 1PC

- 61 M8x25mm Hex Bolt x 1PC 🕽
- 64 M10 Washer x 10PCS (2pcs pre-installed)
- 65 M8 Washer x 4PCS 🔘
- 67 M10 Nylock Nut x 5PCS (1pc pre-installed)
- 68 M8 Nylock Nut x 2PCS 🕖

