

LED UTILITY LIGHT FIXTURE MANUAL

PARTS INCLUDED

LED Fixture

Mounting Plate

Mounting Screws

Connecting Wires

Wire Nuts

x1 x2 x2 x2 x2


THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS OR PORTABLE LUMINAIRES

FOR USE ONLY WHEN WIRING FIXTURE TO JUNCTION BOX (OPTION B).

OPTION A


SIMPLY SCREW INTO EXISTING LIGHT SOCKET

Remove mounting plate from fixture by turning plate counter-clockwise.



Remove cap to expose screw base.

Note: Do not remove screw base cap if you're wiring the fixture to junction box.



3 Screw LED fixture into socket just like a light bulb.



