



WHEN LED IS FLASHING BIDET TOILET SEAT

WHEN LED IS FLASHING



When LED is flashing means
There is water in hot water tank.




WHEN LED IS FLASHING

1. Open the cover base



① Unplug the cord



② Open the water valve and you will here the water sound.



③ After hearing the water sound and plug it back



④ Please make sure the LED is solid.