


NO2 PENDANT // ASSEMBLY INSTRUCTIONS





ABOUT 101 COPENHAGEN

101 Copenhagen is a Danish design brand founded in 2017. With a vision to honor exquisite quality and craftsmanship, the collection encompasses furniture, lighting and accessories in a timeless, yet modern design. With a true passion for materials and refined textures, organic shapes and colours, 101 Copenhagen presents the epitome of classics and must-have novelties for Scandinavian and international interior connoisseurs alike.

OUR CREATIVE DRIVE

The design of 101 Copenhagen is firmly rooted in the Scandinavian soil and nourished by Japanese minimalist aesthetics. Sharing an emphasis on quality materials, techniques and traditions, the meeting between the North and the East is notable in the holistic collections of 101 Copenhagen. The design approach is dynamic and characterised by freedom of expression - creating unique and timeless pieces without compromising on playfulness and individualit.

OUR DESIGN TEAM

An attention to detail and a shared sense of aesthetics is what drives the two main designers of 101 Copenhagen, Tommy Hyldahl and Kristian Sofus Hansen. Merging their backgrounds and experiences from the fashion industry, the Royal Danish Academy of Fine Arts and travels in Japan respectively, a narrative of minimalist, sculptural and conceptual design is evident throughout the collections. Translating and transforming the simplistic inspiration from Japan in a Scandinavian context is all about honouring quality, heritage and materiality while never seizing to compromise on form and function. Trained as an architect, the third designer, Nicolaj Nøddesbo, adds knowledge on innovative light solutions and timeless novelties to the 101 Copenhagen collections. 101 Copenhagen is a curated selection of tactile, bold objects standing out in a crowd and gathers as a whole.

101 COPENHAGEN ©

CONGRATULATIONS ON YOUR NEW PRODUCT FROM 101 COPENHAGEN






No. 2 Pendant

The No. 2 pendant is all about the details and proportions. It has a stunning Art Deco inspired socket detail with vertical lines that add a shimmering quality to the lamp and the warm light coming from the circular opal glass lampshade. Merged, the two elements are extremely elegant, timeless, and quietly glamourous all at once. The No. 2 pendant can be used as a single lamp or in a collection of several pendants together. Designed by Kristian Sofus Hansen & Tommy Hyldahl.

Type: Pendant / Indoor



Always shut off power to the circuit before starting installation work. In some countries electrical installation work may only be carried out by a authorised electrical contractor. Contact your local electricityauthority for advice.

SAFTY INSTRUCTIONS:

Please note the information contained in these instructions and save this manual, also when lamp is already mounted.

GENERAL INSTRUCTIONS:

- Electrical connections may only be carried out by qualified staff.

- The manufactures do not accept responsibility for injuries or defects caused by improper use of this lamp.

- Attention! Before starting the installation, disconnect the power by turning off the circuit breaker, or by removing the fuse at the fuse box.

- Mind to use this lamp for its predetermined function. For example don't mount indoor lamps in outdoor areas.
- Please check all components are complete before installing.
- Don't cover the lamp.
- Don't connect the lamp to power and don't switch it on when it's in packing.

- Bulbs and transformers get very hot during operating. At improper use there is the risk of fire and by changing the bulb you can hurt yourself. Always let cool down!

- If the external flexible cable or cord is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

- Do not mount the lamp on wet or conducting background.
- Make sure that the cables or cords don't get damaged during installation.
- The given main voltage (230V/50Hz) shall not be exceeded.
- Plug and connection elements must be free of tensile strength and torsion force.
- Don't touch bulbs with bare hands.

MAINTENANCE INSTRUCTIONS:

- Before cleaning, disconnect the power by turning off the circuit breaker, or by removing the fuse at the fuse box.


- Mind to clean the surfaces of lamp only.
- Wetness shouldn't get in terminal box or to any conducting part.
- Before you start to clean let it cool down for 10 minutes!
- Cleaning with a soft dry cloth only


ADVICE FOR ENVIRONMENTAL CARE:

Don't put this article to normal domestic waste after the end of its lifecycle. You have to bring it to a staging area for electrical wastes. The materials are recyclable according to their specifications. With the correct recycling of these materials you can make a significant contribution to environmental protection. Ask your local authority for next staging area.


CE MARKING:

By affixing the CE marking to a product, a manufacturer declares that the product meets all the legal requirements for CE marking and can be sold throughout the European Economic Area (EEA).





1. Place a recommended light bulb in the E14 socket. Light bulb is not included.



2. Carefully place the glass globe over the light bulb. Turn clockwise to attach the glass globe.

PENDANT ATTATTACHED DIRECTLY TO THE CEILING Ceiling Height: 220-250 cm


1. Pull the cable from the ceiling through the mounting plate and mount the ceiling cup to the ceiling, with screws and inner mounting plate following in the package. Please make sure it is fixated proberly.

2. When the ceiling cup is attached to the ceiling, lead the fabric cable from both sides into the cable connector. Please make sure the cable relief is tightened.

3. Adjust the cable lenght before you place the cable connector inside the ceiling cup.

How to adjust the cable lenght: Unmount the screw from the small metal ring underneth the ceiling cup. Gently pull down the cable (never pull the cable, while the screw is fastened in the cable) When the lenght is adjusted, please fasten the screw again and make sure it is tightened proberly. Please note the location of the rubber band at fabric covered cable must be placed correctly otherwise the cable will not be fixated properly.

4. Place the cieling cup at the mounting plate and turn right until the cieling cup cover the mounting plate.




PENDANT ATTACHED DIRECTLY TO THE CEILING WITH CABLE IN CEILING ROSE Ceiling Height: 220-250 cm

1. Please mount the cieling cup to the ceiling, with the screws and inner mounting plate following in the package. Please make sure it is fixated proberly.

2. When the ceiling cup is attached to the ceiling, lead the fabric covered cable out of the hole in the cieling cup and attached to the ceiling rose. Please make sure the cable relief is tightened.

3. Adjust the cable lenght before you place the cable connector inside the ceiling cup. How to adjust the cable lenght: Unmount the screw from the small metal ring underneth the ceiling cup. Gently pull down the cable (never pull the cable, while the screw is fastened in the cable) when the lenght is adjusted, please fasten the screw again and make sure it is tightened proberly. Please note the location of the rubber band at fabric covered cable must be placed correctly otherwise the cable will not be fixated properly.

4. Place the cieling cup at the mounting plate and turn right until the cieling cup cover the mounting plate.




PENDANT ATTACHED TO THE CEILING WITH A HOOK SCREW AND METAL WIRES Ceiling Height: 220-250 cm

1. Please mount the cieling cup to the ceiling with a wire and hook and make sure it is fixated proberly.

2. The wires are attached to the inner mounting plate screw holes and connected to the hook in the cieling, please remember to use wire locks to make sure they are fixated properly. When the lamp is installed in correct height, please lead the cable out of the hole in the cieling cup and attached it to the ceiling rose.

3. Adjust the cable lenght before you place the cable connector inside the ceiling cup. How to adjust the cable lenght: Unmount the screw from the small metal ring underneth the ceiling cup. Gently pull down the cable (never pull the cable, while the screw is fastened in the cable) when the lenght is adjusted, please fasten the screw again and make sure it is tightened proberly. Please note the location of the rubber band at fabric covered cable must be placed correctly otherwise the cable will not be fixated properly.

4.Place the cieling cup at the mounting plate and turn right until the cieling cup cover the mounting plate.





Press kit & Imagebank please go to: www.101cph.com Scan the QR code and gain access to our image bank, catalogue and more. Instagram @101cph Pinterest @101cph Facebook @101cph LinkedIn @101cph



Global sales inquiries: sales@101cph.com General inquries: info@101cph.com Support inquiries: support@101cph.com Press inquiries: press@101cph.com Showroom // Østergade 17 3rd Floor, 1100 Copenhagen, Denmark (By appointment only)