



Name	Outside Ø in.	Max bend radius in.	Ferrule	Min-Max T <sub>a</sub> °F
S-Flex 1,5	0,1063	0,3937	B1,5 / M5	-58 - +356
S-Flex 2	0,1496	0,5906	B2 / M5	-58 - +356

**ENG** The fibers may not be installed in less than +41°F ambient. If the fibers are stored in cold place, allow them to warm up for at least 2 h. before starting the installation.

Max bend radius

