

Fx function keys/MAC hot keys



Your keyboard comes defaulted to use Hotkeys. For example, in MacOS the volume keys are single press. If you would like to revert back to F1-F12 keys or vice versa. Press and Hold the Fn + Tab keys for 3 seconds until the LED's flash. To Switch back repeat the process.

Press directly	Press Fn +
ESC	Apple Menu


Press directly	Press Fn +
F1	Screen Brightness -
F2	Screen Brightness +
F3	Launch Pad
F4	Spotlight
F5	Dictation
F6	Do not Disturb
F7	Previous track
F8	Play/Pause
F9	Next track
F10	Mute
F11	Vol -
F12	Vol +

Press Fn + Tab for 3 seconds to toggle

Press directly	Press Fn +
Screen Brightness -	F1
Screen Brightness +	F2
Launch Pad	F3
Spotlight	F4
Dictation	F5
Do not Disturb	F6
Previous track	F7
Play/Pause	F8
Next track	F9
Mute	F10
Vol -	F11
Vol +	F12

Fx function keys/WINDOWS hot keys

Press directly	Press Fn +
ESC	WINDOWS Menu



Press directly	Press Fn +
F1	Screen Brightness -
F2	Screen Brightness +
F3	Launch Pad
F4	Search
F5	Dictation
F6	Lock Screen
F7	Previous track
F8	Play/Pause
F9	Next track
F10	Mute
F11	Vol -
F12	Vol +

Press Fn + Tab for 3 seconds to toggle

Press directly	Press Fn +
Screen Brightness -	F1
Screen Brightness +	F2
Launch Pad	F3
Search	F4
Dictation	F5
Lock Screen	F6
Previous track	F7
Play/Pause	F8
Next track	F9
Mute	F10
Vol -	F11
Vol +	F12