

PAIRING & RECONNECTING YOUR

WOMBAT ASPEN PRO KEYBOARD

RADIO FREQUENCY (RF)BLUETOOTH



PAIRING YOUR WOMBAT KEYBOARD VIA RADIO FREQUENCY (RF)



CHECK THE BATTERY CHARGE

- On the underside of the keyboard, turn the switch to the On position.
- If the keyboard LEDs blink <mark>twice</mark>, the internal lithium battery is charged and ready.
- If the LEDs do not blink, the keyboard must be plugged in via USB cable and charged for a minimum of 5 hours before connecting wirelessly.



Add the Type A-to-Type C adapter to the top of the Type A RF receiver.

Plug into your USB-C computer port.



USB-A USERS

Plug the USB-A receiver into the USB-A port of your computer.





PAIRING YOUR WOMBAT KEYBOARD VIA RADIO FREQUENCY (RF)

3 TO PAIR THE RF WIRELESS RECEIVER, PRESS & HOLD FN +



- Please note our RF receivers are generally pre-paired with our keyboards at the factory.
 In the event your receiver and keyboard are not linked, press and hold Fn + Z for three seconds.
- The LED on the right end of the space bar will blink green twice.
- The keyboard is paired, and you may begin typing.





RECONNECTING YOUR WOMBAT KEYBOARD VIA RADIO FREQUENCY (RF)

- 4 TO RECONNECT THE ALREADY-PAIRED RF WIRELESS RECEIVER, PLUG IT INTO YOUR USB PORT. PRESS & HOLD FN + $\begin{bmatrix} z \\ z \end{bmatrix}$ FOR THREE SECONDS.
 - Once paired successfully, the LED on the Z key will blink twice, and you may begin typing.





Radio

Frequency



PAIRING YOUR WOMBAT KEYBOARD VIA BLUETOOTH



CLOSE ALL BLUETOOTH SETUP DIALOG BOXES

• If any Bluetooth setup dialog boxes are open, close them before proceeding with pairing.

CHECK THE BATTERY CHARGE

Connect up to three devices to your keyboard via Bluetooth.

Pair your first device:



- The corresponding B1 LED will blink purple twice, then turn off.
- The LED on the right end of the space bar will blink blue twice, then turn off.





PAIRING YOUR WOMBAT KEYBOARD **VIA BLUETOOTH**

Add a device

Wombat M68 #1

connect

Make sure your device is turned on and discoverable. Select a device below to

Choose the

Wombat keyboard.

INSTRUCTIONS

Cancel



RECONNECTING YOUR WOMBAT KEYBOARD VIA BLUETOOTH

6 RECONNECT TO A PAIRED COMPUTER HOST

- Ensure the battery has charge and the switch is in the On position.
- Press Fn + B1, or B2, or B3 once and wait for the corresponding LED to blink once.



The LEDs correspond to the three bands of Bluetooth



Bluetooth

Note: The keyboard must be paired whenever connecting to a new computer.



KEY SOURCE INTERNATIONAL

1 (510) 562-5000



info@wombatkeyboards.com

www.wombatkeyboards.com