Thank you for choosing Uahpet!

Uahpet insists on helping pets to live in a way more in line with their nature through scientific and advanced parenting concepts, such as physiology, environment, behavior and psychology.

Scan QR code to get operating instruction manual











Safety Precautions

Failure to comply with the following terms may result in the product not functioning properly or other unexpected losses.

- Please strictly follow the instructions to install and use this product.
- When charging the product or using it while it's charging, please prevent your pets from biting the charging cable to avoid electric leakage.
- Except for maintenance personnel, other people should not repair this product to avoid accidents.
- If children operate the product, please ensure that they are under adult supervision.
- Do not use a charger that exceeds the rated voltage.
- It is recommended to fully charge the product before the first use.
- If you encounter any problems with the product, please contact customer service.

After-sales Service

Accessories Purchase

We recommend that replacing the filter and filter sponge once a month, use with genuine please. www.uahpet.com

Warranty Regulations

From the purchase date on your purchase certificate, the product has a one-year warranty for non-human-caused performance failures, excluding consumables.

Non-warranty regulations

The following conditions (but not limited to) are not covered by the warranty:

- No warranty certificate, missing valid invoice, or exceeding the warranty service period.
- Damage caused by improper use, maintenance, or storage according to the user manual.
- Damage caused by natural disasters such as fire, lightning, or flood.
- The product model or number on the warranty card does not match the actual product.
- Damage caused by non-authorized personnel repair.
- Normal fading, wear, and tear during product use, which are not covered by the warranty.
- Product dysfunction is caused by use in non-compliant areas.
- Random gifts.

ote

In order to provide better products, we will regularly make product improvements. If there are any discrepancies between the product images and the actual product, please refer to the actual product.

uahpet



Wireless Pet Fountain

Stainless Steel

Product manuals

Product Introduction

Parts Description



Product Specifications

Product Model	UYSJ03	Input Voltage	5V = 2A
Product material	ABS+304 grade stainless steel	Rated power	5W
Product Capacity	67oz/2L	Battery	5000mAh
Product weight	710g	Wasserdichte Bewertung	IPX6
Product size	273.4×214.4×213.4mm		

Product List

Stainless steel drinking tray		Stainless steel water tank
Main unit	Filter	Gravity ball filter sponge
Type-C charging cable		User manual

Insert the main unit and make sure the suction cup is tightly fixed.

Product Installation

Confirm that all accessories are included according to the packing list.

Product Installation Steps



Install the filter aligning with the buckle to insert it into place.



Place the stainless steel drinking tray on the water tank.

Product usage instructions

Filter Introduction

- Soak the filter for 15 minutes before first use.
- Filter must be used in conjunction with the main unit.
- For the health of your pet, it is recommended to replace the filter and gravity ball sponge once a month.

Charging Instructions

- Connect the Type-C charging cable (adapter is not included).
- Charging Time: 5h
- The product can work normally while charging.

Function and light description

Press and hold for 3 seconds to turn ON/OFF

When power on, press the button briefly to switch between the Sensing Mode and Timer Mode. The corresponding mode indicator light will light up, accompanied by a short "beep" sound.



Timer Mode/Sensing Mode

C Timer Mode

Water is dispensed every 15 minutes



Sensing Mode Water is dispensed when pets approach the fountain.



Lighting description

- bule light flashing alternately: Charging
- Blue light is always on: Charging completed

Maintenance and Cleaning Instructions

- Please clean the water tank, drinking tray, filter, and gravity ball components regularly.
- Please turn off the machine before cleaning.
- Do not soak or clean the main unit for a long time in water. After cleaning, please wipe it dry.
- The water fountain components cannot be cleaned with high-temperature water (please use water temperature below 50 degrees Celsius).