
Product Description Product Information Notes



List of accessories

User manual x 1

Fluffy-1 Dryer x 1 Wide tooth comb nozzle x 1 Styling nozzle x 1

Concentrator nozzle x 1



Smart button-NTC smart temperature control

Press the smart button and cold/warm air automatically alternate after 3-second cycle.



Temperature button-This will maintain a comfortable body temperature of 38.9°C

Press the temperature button to select cold/warm air.



Airflow speed button-Three airflow speeds

Press the air speed button to select gentle/moderate/strong airflow.



Power button-Slide switch

Push the switch downward to turn off, or upward to turn on.

Product specifications

Model: UCSJ01 Input Voltage: 120V Rotate Speed: 106000rpm Color: White Material: ABS+PPS+30%GF Rated Power: 470W

Dimensions: φ45 × h370mm

Tips

Rotate the air-inlet grille clockwise to clean the fuzz in the dust screen. (Please do not rotate when the power is on)

Safety instructions

Please read the following safety instructions carefully before using the product .lt will help you to use the product safely and correctly, in case of harm to yourself or others.



Failure to follow these instructions may result in fire, WARNING burns, short circuit or electric shock.

1.Do not use the product with wet hands. Do not use the product near bathtubs, showers. washbasins or other utensils that filled of water. Do not use in baths and showers.

2. Ensure that use the standard power socket and the voltage of the connected power supply is consistent with the voltage indicated on the product nameplate when use, at the same time, it should be used separately from other electrical appliances.

3. Never leave while the product is ON. The plug must be unplugged from the socket when meet power failure in use. Please hold the plug and pull it out of the socket.

4.If the product works intermittently, please stop using it immediately.

5.Do not pull the power cord, damage or refit the power cord. If the power cord or plug is damaged or burning hot, please stop using it immediately.

6. Avoid falling or strongly hitting this product.

7.Do not let children play with this product.

8.Do not use near gas or other inflammable products (such as volatile agents, paint thinners, sprays, etc.

9.Do not use the product for any other purpose except blow-drying hair.

10. This product should only be used for pets.

11.Please keep the hair more than 10cm away from the nozzle when use.

12.Please clean the hair at the air-inlet grille regularly.

13.Do not unscrew the air-inlet grille when the power is on to avoid danger.

14. If sparks, redness or other abnormal conditions appear inside the product, please stop using it immediately and contact the suppliers.

Product Maintenance

Maintenance instructions

- Do not repair, disassemble or refit the product by yourself.
- Please turn off the product and remove the power supply after use.
- Do not use thinners, benzene and other liquor to clean the product.
- Store the product in a safe, dry and clean place.

Normal fault types and handling methods are shown as below:

	Phenomenon	Possible Cause	Solutions
	Do not work	The connected power socket is not energized.	Make sure the socket is energized.
		The voltage of the connected power supply is inconsistent.	Ensure that the voltage of the connected power supply is consistent with the voltage indicated on the product nameplate.
	Work intermittently	Product is under the overheat protection.	Check whether the air inlet and air outlet are blocked by fluff, hair or other things.



smart care for pets

Have a question for uah? Email us:

kony@uahpet.com





Fluffy-1 Dryer User Manual