



WINDBREAKER BRACKET SYSTEM

WINDBREAKER BRACKET SYSTEM

The WindBreaker Bracket System has been engineered for exterior installations in all types of weather. The banner system features an aluminum housing with an adjustable fiberglass arm cantilevered to keep the banner tight. The flexible arm spills the wind pressure from the pole and banner to prolong the life of your banner program.

- Adaptable to any type of pole regardless of shape, size, or material.
- Equipped with a cantilevered flexible fiberglass arm that spills the wind off of the banner, thereby adding longevity to your banner program. Standard arm length is 30". Custom lengths available upon request.
- Bracket shoes allow for up to 8" of adjustability in height with out removing shoes.
- Built with 100% extruded aluminum stock; when installed with stainless steel banding there are no oxidizing materials on your poles.
- Engineered to withstand 70 mph winds when installed with Band-it strapping material.
- Simple to install and the arms remove easily when your banner program is not in use.
- See our configurations for a complete parts listing.
- Includes a six year limited warranty.

WARRANTY

Wind Breaker Banner Brackets are guaranteed for six (6) years against defects in material and workmanship when installed according to our installation instructions. Please note - any banner programs up over 30 days must use "Band-it-It" stainless steel banding (Model #206) and the banding must wrap around the pole twice (x2) before clamping the buckles to qualify for warranty. After three (3) years we prorate our warranty by 50% from the date of delivery. Also, as noted in your instructions, inspect your banner installation 30 days after initial installation and every 60 days thereafter making any appropriate adjustments. Please verify with your light pole manufacturer or a structural engineer to insure that the light pole is suitable for a banner bracket and a banner application.