



PAN TO BURNER SIZE GUIDE

Pan Size	Burner Size
26cm – 38cm	200mm
34cm – 46cm	300mm
46cm – 60cm	400mm
70cm – 80cm	500mm
80cm – 90cm	600mm
90cm – 100cm	700mm
100cm – 115cm	800mm
115cm – 130cm	900mm

