

## **VIVOTEK Mounting Accessories**

AM-71B\_V02 Conduit Box

## Installation Guide

Revison History:

(3)


wall.

Rev. 1.0: Initial release

Part no.: 5019042700 Accessory Ordering part no.: VIO100220401

Compatible VIVOTEK Cameras


Hole Type	Applicable Cameras	Screw	No. of Screws
A	FD9368-HTV, FD9388-HTV	M4x10	3
A	FD9389 series	M4x8	3
В	IT9388-HT	M4x8	3
С	FD9360-H, FD9380-H	M4x8	3
D	IT9389-H-V2	M3x7	3



Attach the included alignment sticker to a preferred position.

behind the wall allows, you may also pass cables through the


Drill holes on the wall and install the junction box. If space




- Loosen and remove the camera top cover. (Using one of the supported cameras as an example)


6

Pass the camera's Ethernet cable through the center hole of the box and the rubber seal.







Install the waterproof components of the cable gland to your Ethernet cable following the QIG of your camera. The cable




A 3/4" conduit is required for routing the cables with waterproof connection.



Install the cable gland and pass cables through it.





A: FD9389 series, FD9368-HTV, FD9388-HTV

 د ه ه

> O B O A

Install the camera using the corresponding mounting holes.

A C

° G

B: IT9388-HT

D: IT9389-H-V2


O A

( 🕑 `o


10


**C**: FD9360-H, FD9380-H

Make sure the rubber seal is properly installed to the center hole. The outer rim of the seal must be through and cover the edge of the hole.



9 Secure the top cover by fastening 3 cross-head screws.





Open a live view console and adjust the shooting direction. Refer to the camera's QIG for more information.

Secure the camera top cover.

