


# INSTRUCTIONS | FULLY PADDED ROCKING CHAIR (FC-368-CGY)


### **UNFOLDING STEPS**




1. Remove the bag, keep it upright.



 $\hbox{2.Put down the two rockers.}\\$ 



3. Reverse force on the armrest and back bar (diagonal) until the chair is fully extended.



4. Install the buckles at the bottom.





# DESIGNED, BUILT AND TESTED IN THE WILD, FOR THE WILD.

Your Portal table is covered by a 12-month quality warranty.

#### **Questions? Talk to Us**

Email: Info@portaloutdoors.com www.portaloutdoors.com

f @PortalOutdoorsGear

@portaloutdoorsusa

## **Safety Tips**

- ·Do not use this product in an elevated position or on a platform that presents potential drop/fall hazards!
- ·Before using this product, read any provided instructions.
- ·Before using this product, ensure that it is in good working order/condition
- and properly constructed/set up as detailed in any provided instructions.
- ·Maximum load for this chair is 400 LBS. Never exceed this listed weight capacity.
- ·Ensure chair is fully open before sitting in chair.
- .Do not stand or climb on chair.
- ·Beware of possible tipping points when using this product. Care should be taken to avoid tipping while seated.
- ·Always be aware of your surroundings when using this product.
- •Ensure product is on level, stable ground when in use. Do not use this product on uneven ground.
- ·Keep away from open flames/heat sources.
- ·Keep away from potential water hazards.
- ·Be aware of moving parts. Keep hands and fingers away from moving parts.
- If product includes a cupholder, do not put hot beverages in cupholder.
- •This product is intended for personal use only, not for commercial use. Only use this product for its intended use.