



USER MANUAL

PEANUTS SNOOPY LED CLOCK

Please ensure that you thoroughly read the user manual before operating and keep it easily accessible for reference at all times.

HOW TO USE

USAGE TIPS:

1. The setup status will indicate objects entering with a blinking display.
2. To quickly change the time, press and hold the '+' or '-' button.
3. Briefly press the '-' button to toggle the notification on or off
(Check for 'AL' display)

CHARGING INSTRUCTIONS:

1. Connect using a Type-C cable.
2. After the LED display screen turns on, the system will switch to clock mode with a beep sound after approximately 3 seconds.

TIME SETUP:




1. In clock mode, press and hold the left 'M' button for 2 seconds to enter the time setting mode.
2. Use the '+' button to select between 12-hrs and 24-hrs format, then press the 'M' button.
3. Use the '+' and '-' buttons to set the hour and minute, and press the 'M' button to complete the time setting.

ALARM SETUP:

1. Briefly press the 'M' button to switch to alarm mode.
 2. In alarm mode, press and hold the left 'M' button for 2 seconds to enter the alarm setting mode.
 3. Use the '+' and '-' button to set the desired alarm time, then press the 'M' button.
 4. To set the snooze duration between 5 to 60 mins, press the 'M' button to complete the alarm setting.
-

HOW TO USE

TURNING OFF THE ALARM:

1. The alarm will last for 2 mins, indicated by blinking 'AL' on the screen.
2. Touch the paw    on top of the device to turn off the alarm while it is ringing.
3. If the alarm is not turned off before it stops, the alarm sound will repeat again at the set time.

AUTOMATIC BRIGHTNESS SENSOR SETTINGS:

In clock mode, press and hold the '+' button to toggle the automatic brightness sensor function on or off. The brightness detection sensors adjust the display based on the surrounding environment, making it brighter or darker accordingly.

NIGHT MODE SETTING:

1. Press the 'M' button 3x in the clock mode to access the night mode setting.
2. Use the '+' or '-' button to set ON/OFF status.
3. Press and hold the 'M' button in the ON display window to set the night mode time zone.
(Order: Night mode start time > Night mode end time)
4. After setting the time, press the 'M' button to complete the night mode setting.



BRIGHT



MEDIUM





DARK



OTHER FEATURES:

In the clock and alarm mode, adjust the brightness by briefly pressing the '+' button. (Three brightness levels are available)

HOW TO USE



1 Backup Battery Compartment





2 Auto Brightness Sensor

3 Mode Setting / Confirm

3 Brightness Adjustment / UP

4 Alarm ON/OFF, Down



5 USB Output Port

6 USB Output Port

7 Type-C Input Port

CAUTIONS

*For your safety, please read the following precautions before using the product.

- Use this product solely for the purposes listed.
 - Do not disassemble or modify the product.
 - Make sure to avoid the entry of foreign objects into the clock.
 - Avoid bending or pulling the USB power cable excessively.
 - Be cautious of potential damage or injury from strong impacts or improper usage.
 - Keep the product away from firearms and heat sources to prevent deformation.
 - Ensure that children and pets cannot access the product.
 - Do not use a damaged charging cable.
 - Place the product on a flat and stable surface, away from direct sunlight, excessive heat, and moisture.
 - If the product will not be used for an extended period (at least 1 month), remove the battery to prevent corrosion. Avoid exposing the product to water, moisture, or handling it with wet hands.
 - We are not liable for any damages or defects resulting from user negligence.
-

SPECIFICATIONS

Product Name: PEANUTS SNOOPY LED CLOCK

Item No: SN021-080

Material: ABS, Soft PVC, LED Mirror Display

Size: 6.23" x 4.79"

Input Voltage: 5V/2A

Output Voltage: 5V/1A

Date of Manufacture: April, 2022

Country of Origin: China

Components:

(1) PEANUTS SNOOPY LED CLOCK

(1) Charger

WARRANTY & TROUBLE SHOOTING

Warranty & Customer Service

Subject to the conditions of this Limited Warranty, Bo Friends warrants this product to be free from defects in design, material, & workmanship at the time of its original purchase by a consumer, & for a subsequent period of Thirty (30) days. Should your product need warranty service, please contact customer support by e-mail support@bofriendsus.com

Battery Information (If Applicable)

A rechargeable battery has a long service life if treated properly. A new battery or one that has not been used for a long period of time could have reduced capacity the first few times it is used. Do not expose the battery to extreme temperatures, never above +50°C (+122°F) or below -10°C (+14°F). For maximum battery capacity, use the battery at room temperature. If the battery is used in low temperatures, the battery capacity will be reduced. The battery can only be charged in temperatures between +10°C (+50°F) and +45°C (+113°F).
