

Installing a Map Card on the Yamaha PWC Display:

NOTE: If your GPS signal is low or non-existent, a map will not display even with a Maps card.







Remove meter backing. Turn the cap covering the USB port to the left to unlock and uncover the port. Insert the USB Maps card. Replace the cap and turn to the right to lock.



Replace the meter backing and reinstall the (2) 10mm bolts. Close the hood. Reboot the meter to read the Maps card.





WARNING: Ensure the USB port cap is securely covering the Maps card. There will be no warranty on Maps cards that are ruined due to water exposure.

02/07/2022 EnovationControls.com