

## CirrusSense™TDWLB-G2 Battery Replacement.



## DESCRIPTION

When replacing your TDWLB-G2 battery, please follow the important procedures listed below:

- 1. Remove the Cap by turning it counter clockwise (see below photo)
- 2. Place a small screw driver blade between plug and socket and pry up to remove plug from socket. Plug only fits one way. Remove battery.
- 3. Wait a minimum of 90 seconds before inserting the new battery. The transducer needs to reset before connecting new battery. Plug back in.
- 4. Replace old Cap O-ring with new one supplied.
- 5. Replace cap turning it clockwise until it stops, lining up the arrows.

