

User's Manual

# AIR-PURIFIER

**KJ25FE-H1**



Please read this manual carefully  
before using this air purifier and  
save it for reference.

**For Model: KJ25FE-H1**



Alen Air Purifier  
Great value with HEPA performance.

---

## CONTENTS

■ Important Safeguards . . . . .	1
■ Features . . . . .	1
■ Know Your Air Purifier . . . . .	2
■ How to Assemble and Use . . . . .	2
■ How to Clean and Maintain . . . . .	5
■ Trouble Shooting . . . . .	6
■ Model & Specification . . . . .	6

## Important Safeguards

- To avoid electric shock and fire hazards, plug the air purifier directly into an appropriate electrical outlet (120V AC). Do not alter the electrical cord or plug in any way.
- Do not insert foreign objects into the air intake or outlet grills. This may result in damage to the air purifier or electric shock.
- Do not block the air intake or outlet grill as it could damage the air purifier.
- Do not use the air purifier outside or in a wet environment such as a bathroom. Do not let the air purifier come in contact with water.
- Discard the plastic packaging around the filter before use, otherwise it could cause damage to the motor.
- Unplug the air purifier when not in use.
- Only run the unit on a flat, stable surface. If wall mounted, ensure that the air purifier is level and securely mounted.
- Do not place anything on top of the unit.
- Do not place the unit directly on or against soft furnishings (for example curtains), near heat sources (for example heaters, ovens, fireplaces, etc), or near combustible gases or oxygen tanks.
- Do not touch any part of the air purifier if your hands are wet.

## Features


- Patented design
- Pre -filter
- HEPA filter
- Built-in ionizer
- Filter replacement indicator
- 12 hour timer
- 4 fan speed selection
- Soft push-button controls

## Model & Specification

Model	KJ25FE-H1
Voltage/Frequency	AC 120V /60Hz
Electric current (A)	0.8
Coverage Area	400sq feet
Weight	18.2lbs
Dimension (LxWxH)	18.5' X 9' X 17.5'


## Know Your Air Purifier

### Exploded View




## How to Assemble and Use

### Where to Locate



- Keep the unit at least 6 feet from electronically sensitive devices such as a TV, radio, etc to avoid interference.



- Keep both sides of the unit at least 4 inches from a wall.




- Do not blow air directly into the air purifier.



- Do not place the unit where the air intake or outlet grille could come in contact with a curtain.




- Placing the unit close to the source of the air pollution can improve the overall air quality of the room more quickly.




- Place the air purifier in a well-ventilated location of the room.

## How to Install The Filter

---




- With the front of the unit facing up, pull up on the lower end of the front cover as shown in the diagram.




- After pulling up, push the cover toward the display panel at the top of the unit as shown in the diagram.



- Grasp the upper parts of the right and left recesses, and remove the filter.




- Remove the filter from the plastic bag and insert the filter into the air purifier with the arrow pointing inward.



- Insert the top of the front cover first and then snap in the lower part of the cover.

## Control Panel



① Plug the unit into an electric outlet, the device will be ready to run. Press the ON/OFF key to start running, repress it to stop.

② Press the IONIZER key to start the ionizer while the fan is running, repress it to stop.

③ When a filter is replaced, press the reset button to reset HEPA filter indicator to zero.  
Note: this feature will only work when all five bars of the filter indicator are lit.

④ When the air purifier is turned on, the fan will run at medium speed for 3 seconds before running at low speed (default speed). Press the SPEED key each time, the fan speed will recycle as shown below

Low → Medium → High → Strong  
↑


⑤ While the fan is running, press the "TIMER" key to preset the running time, the presetting time will recycle each time pressing this key as shown below.

1h → 2h → 3h → 4h → 5h → 6h → 7h  
↑  
Cancel ← 12h ← 11h ← 10h ← 9h ← 8h

## LED Display

### 1. Fan Speed Indicator

Low : 1 bar is lit  
Medium: 2 bars lit  
High: 3 bars lit  
strong: 4 bars lit



### 2. Timer

The digital display timer displays the number of hours the unit will run before stopping. This can be set from 1 to 12 hours.


### 3. Ionizer

All four ionizer symbols are lit when the ionizer is on.

### 4. HEPA Filter Replacement Indicator

When all five of the bars are lit, the filter should be replaced. After replacing the filter, press the RESET button to reset the filter indicator.

## How to Clean and Maintain



- With the front of the unit facing up, pull up on the lower end of the front cover as shown in the diagram.



- Clean with a vacuum and clean with a damp cloth, if necessary.



- Do not clean with chemical solvents or corrosive materials as they may damage the unit.

### Filter replacement

- The HEPA filter will last for 6 to 12 months depending upon use.
- Do not insert a used filter in the reverse direction.
- Only use Alen authorized HEPA filters

## Trouble Shooting

Problem	Solution
Unit will not operate	<ul style="list-style-type: none"> <li>• Check to make sure the front cover is inserted properly</li> </ul>
HEPA Replacement Indicator is lighted after the filter has been replaced.	<ul style="list-style-type: none"> <li>• Turn the unit on and press the RESET button until the HEPA filter indicator lights turn off.</li> </ul>

## Alen Air Purifier Lifetime Warranty

Alen offers the industry's first Lifetime Warranty coverage for all Alen air purifiers and air cleaners. This Lifetime Warranty reflects Alen's commitment to providing our customers with the best value and performance of any air purifier in the market. Alen warrants your Alen Air Purifier to be free from defects in material or workmanship for as long as you own your air purifier. Alen recommends replacing the HEPA filter every six (6) months to maintain the performance, durability and longevity of your Alen air purifier.

To participate in the Alen Lifetime Warranty, customers need to complete the following:

1. Complete product registration form online at [www.Alentech.com](http://www.Alentech.com)
2. Participate in Alen's Filter Replacement Program. Two replacement HEPA filters will be shipped to you every year on your registration anniversary for as long as you own your machine. An Alen representative will contact you for payment details.

Alen's obligation and liability under this Lifetime Warranty is limited to repairing or replacing (at Alen's sole discretion) the defective unit and paying the freight cost of shipping the replacement unit to you. This Lifetime Warranty does not cover replacement filters. In the event of a malfunction or failure of your Alen Air Purifier, please contact Alen directly at [www.Alentech.com](http://www.Alentech.com). The return authorization number must be clearly written on the outside of the shipping box or the shipment may be refused. Your Lifetime Warranty remains in effect only if your Alen Air Purifier is:

1. Operated in accordance with the instructions provided in the Alen User Manual.
2. Replaced the HEPA filter with Alen replacement filters at least once every six (6) months via Alen Filter Replacement Program.
3. Connected to a proper power supply (see voltage label on machine).
4. Shows no evidence of tampering, mishandling, neglect, accidental damage, modification, and/or repair done to the Alen Air Purifier by anyone other than authorized Alen service personnel.
5. Your warranty registration has been completed and submitted to Alen.
6. This Lifetime Warranty cannot be transferred.

This Lifetime Warranty is provided by Alen Corporation, a Delaware Company.

ALEN DISCLAIMS ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTEE OR REPRESENTATIONS AS TO THE SUITABILITY FOR ANY PARTICULAR PURPOSE, PERFORMANCE, QUALITY AND ABSENCE OF HIDDEN DEFECTS, AND ANY REMEDY FOR BREACH OF CONTRACT, WHICH BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND



FITNESS FOR A PARTICULAR PURPOSE. EXCEPT AS PROVIDED IN THIS AGREEMENT, ALEN FURTHER DISCLAIMS ANY RESPONSIBILITY FOR LOSSES, EXPENSES, INCONVENIENCES, SPECIAL, INDIRECT, SECONDARY OR CONSEQUENTIAL DAMAGES ARISING FROM OWNERSHIP OR USE OF THE PRODUCTS.