

SOLAR LANTERN (with 3 screws) BATTERY REPLACEMENT INSTRUCTIONS

If your Solar Lantern stops lighting up even with 6-8 hours of direct sunlight, you may need to replace the battery as follows:




Figure 1

- Remove frame support wire and collapse the lantern flat to allow access to the bottom of the solar housing
- Slide the ON/OFF switch to OFF (see figure 1)
- Using a small Phillips head screwdriver, unscrew the three screws (see figure 1) and remove the cover to expose the inside of the solar housing (see figure 2)
- Remove existing AAA battery and replace with the new rechargeable AAA battery.
- Replace cover by aligning ON/OFF switch to hole, fasten screws, slide ON/OFF switch to ON, and reassemble lantern.




Figure 2

Please visit our website for a how-to video and for more information regarding this battery and where you may purchase a replacement:

www.allsopgarden.com/video