










QUADRANT

Trælåge PUSH
 Wooden door PUSH
 Holztür PUSH
 Puerta de madera PUSH

No.
 51383802
 51387802
 Træe PUSH





	 <p>80 x1</p>	 <p>81 x1</p>	 <p>82 x1</p>	 <p>57 x6</p>
	 <p>70 x2</p>	 <p>71 x2</p>	 <p>72 x4</p>	



QUADRANT

Trælåge PUSH
Wooden door PUSH
Holztür PUSH
Puerta de madera PUSH










Vejledning
51383802
51385702
51387802
51575702
Trae PUSH




QUADRANT

Glaslåge PUSH
 Glass door PUSH
 Glastür PUSH
 Puerta de cristal PUSH

No.
 51383802_90
 51387802_90
 Glass PUSH

			75  x2	71  x2	78  x4
	77  x1	80  x1	81  x1	82  x1	57  x6



Q U A D R A N T

Glaslåge PUSH
Glass door PUSH
Glastür PUSH
Puerta de cristal PUSH

Vejledning
51383802_90
51387802_90
Glas PUSH

