

ProScope (USB models)

Chrome and Android

Chrome

Have the ProScope plugged in and go through a full restart of the Chromebook. This will put your Chromebook in the startup series. You can then utilize hangouts to choose which device you wish to use, onboard webcam or the ProScope. This choice will carry through to the actual Camera app. If you want to try a different app than the native Camera app, we have found that the free "Webcam Toy" app from the Chrome Web Store works well.

<https://chrome.google.com/webstore/detail/webcam-toy/lfbgimoladefibpklnfmkpknadbkklade?hl=en>

Android

You can download the free UsbWebCamera app or pay \$3.45 for the UsbWebCameraPro app which just eliminates the ads. Both are on the Google Play Store and then use the ProScope HR or HR2 with any Android based device running 4.1 or later with the addition of a USB OTG adapter.

(Free) UsbWebCamera can be downloaded here:

<https://play.google.com/store/apps/details?id=com.serenegiant.usbwebcamera>

(\$3.45) UsbWebCameraPro can be downloaded here:

<https://play.google.com/store/apps/details?id=com.serenegiant.usbwebcamerapro>

Questions?
800-441-6877
support@bodelin.com