KAMBUKKA°

MICROUAVABLE COMPARTMENT


USAGE RECOMMENDATION

- Fill the microwavable compartment with your favorite food at a desired temperature – do not overfill. Or place the filled compartment in the microwave and heat to desired temperature.
- Place the lid on the plastic compartment by twisting until tightly closed.
- Lock the microwave compartment into the Stainless Steel body by twisting.
- Suitable for both hot and cold food.
- Hours it keeps food hot: graph 1
- All of our Kambukka food jars have been rigorously tested at full volume and under a constant temperature.
- · Keeps food fresh for hours
- The compartment can be hot after microwaving
- The compartment is not intended for cooking on a stove or in a conventional oven
- Extending the heating temperature or the heating time in the microwave may damage the container or can leave stains
- Do not use utensils with sharp edges in the container. Do not use the product if damaged.
- If you fill the food jar with a boiling liquid, allow the liquid to cool down for at least 3 minutes before you close the lid. If not, internal pressure build-up can lead to leaks and severe burns.
- Do not keep food in the micro compartment for longer than 24 hours.
- Make sure the lid is screwed down completely.
- Keep out of reach of children when filled with hot liquids.
- Not suitable for children under the age of 3.

CLEANING INSTRUCTIONS

- Wash all parts with soapy water before first use.
- Don't use cleaning substances containing bleach, chlorine, scouring agent and/or harsh chemicals.
- This product is dishwasher safe.
- Always store with lid removed to allow parts to dry completely.

Thirsty for more? Combine your food jar with on of our trendy bottles or mugs. Visit www.kambukka.com for more details.





GRAPH 1: HOURS HOT

