

MATRIX²

STEREO WIRELESS BLUETOOTH HEADPHONES

model: AF62

USER MANUAL

part of the AIR-FD) series

TABLE OF CONTENTS

| Product Overview | 1 |
|--|-----------------------|
| Charging | 2 |
| Powering On and Off | 2 |
| Pairing with Bluetooth® Devices iPhone®, iPad®, and iPod touch® Android™ Phones and Tablets | 3 |
| Computers and Laptops | |
| Pairing with Bluetooth devices using NFC | 4 |
| Connecting to Paired Devices | 4 |
| Using the Matrix Headphones Adjusting Volume Controlling Phone Calls Controlling Media Playback Additional Functionality | 4 4 5 5 6 |
| Using as a Wired Headphone | 6 |
| Safety and Care | 6 |
| Specifications | 6 |
| Troubleshooting | 6 |

MATRIX²



MEElectronics and its logo are registered trademarks of S2E, Inc. All rights reserved.

iPhone®, iPad®, iPod touch® is a registered trademark of Apple Inc.

Android™ is a registered trademark of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by MEElectronics is under license. Other trademarks and trade names are those of their respective owner.

MATRIX²

AF62 Stereo Bluetooth Wireless Headphones





- A microphone
- B LED indicator
- C power/call button ∪
- D volume down V-
- E volume up V+
- F 3.5mm audio jack



Right Ear Cup

- G USB port for charging
- H next track ▶►
- I play/pause button ▶/II
- J previous track I◄<

CHARGING

*** You must completely charge the headset before the first use ***

Connect the USB charging cable to any powered USB port and to the USB jack on the right ear cup. The red LED indicator will light solid while charging. Charge time is typically 3-6 hours for the first charge and 2-3 hours for subsequent charges. When the battery is fully charged the bright red LFD indicator will run off.

Note: Bluetooth will function when the unit is charging, but leaving the Matrix on can increase charge time. The headphones can also be turned off and used with the included audio cable while charging. This will not affect charge time.

When the battery is low, the red LED will turn on. The Matrix will also provide a low battery voice notification every minute.

POWERING ON AND OFF

- a) To power on, press and hold the Power button for approximately 3 seconds. The Matrix will say "power on" and the blue indicator light will flash every second to show the power is on.
- To power off, press and hold the Power button for approximately 5 seconds. The Matrix will say "power off."

PAIRING WITH BILUFTOOTH® DEVICES

*** It is only necessary to pair your Matrix once

- a) Open the Bluetooth menu* on the device you wish to pair. Some devices require you to select "search for devices" or "add new devices" in order to create a Bluetooth pairing.
- b) Make sure the Matrix is off and within 1 meter of your device. Initiate pairing mode by pressing the Power button for 6 seconds, until you hear ready to pair, turn on Bluetooth, the pin code is 0000." The red and blue LEDs will flash in an alternating pattern while the Matrix is in pairing mode. (Note: The Matrix will enter standby mode if not paired within 5 minutes.)
- c) Wait until you see "Air-Fi Matrix 2" appear on your device
- d) Select "Air-Fi Matrix 2" on your device and allow to pair. If your device asks for a pin, enter "0000". Once pairing is complete and a connection is established, the blue LED on the Matrix will be on continuously

If pairing fails, please repeat steps a) through d) above

*Locating the Bluetooth menu:

iPhone, iPad, and iPod touch

- a) On your device, go to Settings
- Select Bluetooth (Bluetooth is under the General menu in iOS 5.1.1 and older); if Bluetooth is not on, turn it on. The iPhone/iPad/iPod will automatically search for new devices

Android Phones and Tablets

- a) On your device, go to Settings menu
- b) Select Wireless & Networks → Bluetooth and if Bluetooth is not on, turn it on. Select "Search for Devices" if your phone or tablet does not automatically search for new devices

Computers and Laptops

Visit www.meelec.com/bluetooth for pairing, connecting, and audio device setup for computers.

If pairing fails after several tries, please refer to your device's user manual for further information.

PAIRING WITH BLUETOOTH DEVICES USING NFC

Note: When the volume reaches the minimum or maximum level there will be two short tones

- a) Put the Matrix in pairing mode
- b) Place the NFC-compatible device against the left ear cup of the Matrix until pairing is complete.
- A dialog box should automatically appear, if the dialog box does not appear, re-position the device until it does
- d) Follow the instructions on the screen to pair the device with the Matrix

CONNECTING TO PAIRED DEVICES

*** The Matrix must have been previously paired with your device before you can connect ***

When the Matrix is turned on and not in pairing mode, it should connect to the last connected device automatically. If the last connected device discoverable, the Matrix will connect to other paired devices in the order of last connection.

If the Matrix does not connect and remains in standby mode, a short press of the Play/Pause button will connect to the last connected device with Bluetooth on and within range.

Note: On some PC and Mac computers you will need to manually enable Bluetooth audio every time you connect

USING THE MATRIX HEADPHONES

Adjusting Volume

| Function | Operation | Notes |
|-----------------|--|--|
| Increase volume | Single press or press and hold the Volume Up V+ button | When the volume reaches the minimum or maximum level the Matrix will produce a short tone. |
| Decrease volume | Single press or press and hold the Volume Down V- button | matrix will produce a short tone. |

Note: In standby mode and while playing media with most devices, volume adjustments will only change the volume of the Matrix. Adjust device volume as needed to further increase or decrease the volume. During a phone call the Matrix will control device volume. Some newer devices use AVRCP 1.3 Bluetooth Profile. which will allow the Matrix to change the device volume at all times.

USING THE MATRIX HEADPHONES (Continued)

Controlling Phone Calls

| Status | Function | Operation |
|--|--|---|
| Incoming | Answer a call | Single press the Power () button |
| call | Reject a call | Press and hold the Power 🖰 button for 2 seconds |
| Call in progress | End a call | Single press the Power U button |
| Call in progress, phone handset active ¹ | End a call | Single press the Power 0 button |
| Call in progress, second incoming call | Answer new call and place the current call on hold | Single press the Power () button |
| | Reject incoming call | Press and hold the Power 🖰 button for 2 seconds |
| One call active, one on hold | Switch active calls | Press and hold the Power \circlearrowleft button for 2 seconds. There will be a single tone to indicate the calls have been switched. |
| | End current call and switch to call on hold | Single press the Power () button |

¹If you answer a call from your phone instead of the headset, most phones will activate the phone handset, not the Matrix.

Controlling Media Playback

| Status | Function | Operation |
|---------------------------------|----------------------------------|----------------------------------|
| No media playing ¹ | Play media | Press the Play/Pause ►/II button |
| Media playing | Pause media playback | Press the Play/Pause ►/II button |
| Either media | Skip to next track | Press the Next ►► button |
| playing or stopped ² | Restart the track/previous track | Press the Previous I◀ button |

 $^{^{1}}$ You may need to focus on the media player application for initial playback to start. 2 Not all media players support this functionality.

Note: If you answer or make a call while listening to media, the media will be paused until the call has ended.

١١.

USING THE MATRIX HEADPHONES (Continued)

Additional Functionality

| Action / Status | Button Function | Sounds |
|--|----------------------------------|------------|
| Activate voice command / dialing ¹ | Single press the Power () button | Short tone |

¹ Not all devices support this functionality. For more information, refer to the user manual for your device.

USING AS A WIRED HEADPHONE

The Matrix comes with a 3.5mm audio jack on the left ear cup and an audio cable for wired use. This allows use with in-flight entertainment devices, devices that don't have Bluetooth or aren't paired, or when the battery is depleted.

The Matrix can be used wired while still connected via Bluetooth to another device. Bluetooth audio takes precedence over wired audio; if a Bluetooth device is connected while listening to wired audio, wired audio will partially mute when audio is transmitted via Bluetooth. Wired audio will resume approximately 10 seconds after the Bluetooth transmission ends.

SAFETY AND CARE

- a) When not in use, power the headphones off and store in the included protective pouch.
- Clean with a soft cloth, damp with diluted soap water solution if necessary. Never use chemical cleaners.
- There are no user replaceable/reparable parts in the headset. Disassembling it will void your warranty.
- d) Do not expose the headphones to liquids. If submersed in water, do not turn the device on until completely dried.
 Note: liquid submersion voids the warranty.
- Battery performance will be severely decreased when stored in extreme temperatures: below -10°C/14°F or above 45°C/113°F.

SPECIFICATIONS

See the Air-Fi Matrix product page at $\ensuremath{\text{www.meelec.com}}$ for product specifications.

TROUBLESHOOTING

Please visit www.meelec.com/bluetooth for the troubleshooting information

