



Content



1 X SCREW WITH THREADLOCKER



4 X WOOD SCREW



1 X MOUNTING PLATE



1 X CANDLE LOW

Mounting


It's a matter of taste. You can mount your legs where you think it looks the best.

We like to place them like this: 65 mm from the front/back to the center of the leg and 65 mm from the side of the finished cabinet to the center of the leg.

1. Place the furniture with the backside towards the floor, preferably on a thin carpet.
2. Mark the position of the screws on the bottom of the furniture using a mounting template or by measuring.
3. Hold the mounting plate in place and attach the top left screw. Make sure that the mounting plate is in the correct position and then attach the rest of the screws.
4. Attach the threaded rod with threadlocker to the mounting plate, then attach the leg to the threaded rod.
5. Lift the furniture up from the floor without applying any tilted or horizontal pressure to the legs. Attach it to the wall and adjust the legs before the threadlocker dries.

NOTE: Do not straighten up the furniture by tilting it, as this can cause damage to the legs and the mounting plates since they are only made for vertical pressure.

Mounting template



Safety

Please always follow the safety instructions that apply to your IKEA products. Always secure the cabinets to the wall using the METOD suspension rail. Also, make sure that the wall can support the weight.

We are happy to help!

info@helsingo.com
+358 20 718 1510

Show how beautiful it looks

Share the A.S.Helsingö additions in your home using
@a.s.helsingo and #ashelsingo.