


Sent this copy to: INKIN TATTOO After-Sales Department.
3/F 7(7Dong), No.289 Fahua North Road
Jinyi Dushi New District, Jinhua 321036
Zhejiang China
TEL: +86-153-5693-3972
Email: admin@inkintattoosupply.com



INKin machines purchased from our online stores or authorized distributors worldwide come with a one-year warranty from the date of purchase. If you find that the product is malfunctioning during the warranty period, please contact our After-Sales Team Email: admin@inkintattoosupply.com.

Warranties do not cover:
Damage to the product due to a human factor.
Product damage due to external electrical failure or any accident.



WARNING:

- It is recommended to use the included charging cable.
- This device don't support fast charging/super fast charging, fast charging may get damage the battery.
- Lithium-Ion battery packs are shipped partially charged . Charge the battery pack before first use.

WARRANTY CARD

PRODUCT NAME: _____
 DATE OF PURCHASE: _____
 WHERE PURCHASED: _____
 ADDRESS: _____
 EMAIL: _____
 MY SIGNATURE BELOW ACKNOWLEDGES THAT I
 HAVE READ ,FULLY UNDERSTAND, AND ACCEPT
 THIS LIMITED WARRANTY AGREEMENT.
 SIGNATURE : _____ DATE : _____

NowTA I

5

6

1

Technical Specifications:

Motor: INKIN customized motor
 Material: Aircraft Aluminum
 Dimension(Φ X L): 32mm x 130mm
 Net Weight: 150g without battery
 Battery capacity: 2000mAh (ICR18500 lithium)
 Working time: 6-8 hours
 Rpm: 12000rpm 12V
 Recharging time: 3 hours
 Length of Stroke: 3.5mm
 Suggestion Voltage: 6-8V
 Color: Red/Black/Silver
 USB Charging cable included.
 Created and manufactured in China by INKIN
 60 day replacement warranty from date of purchase for non-functioning batteries only.



Package Includes:

NowTA I ,
 2000mAh battery x 2 ,
 Battery Charger ,
 USB cable,
 Manual



Instruction

Long press the \oplus/\ominus button to turn on/off the machine.

Voltage Adjusting

The Voltage could be adjusted through button \oplus and \ominus respectively with the voltage of 0.1V on each press

Quick Adjusting Voltage Mode

Long press the \oplus or \ominus button to quickly adjust the voltage.

Click on ⏻ to turn your machine Stop/Go

2

3

4