

HAMR

Highly
Adaptive
Motor
Retainer

29/38 Adapter Kit



29mm
Motor



29mm Motor
Centering
Sleeve



38/29 Offset
Ring



38/29 Stepped
Ring

HAMR
Sleeve




HAMR 38mm
Pre-Installed



HAMR
Cap

Slide the motor assembly into the 38mm motor mount of the rocket. If the Centering Sleeve is too tight to easily slide into the motor tube, sand the outside surface with fine sandpaper for an easy, slip fit. Continue to slide the motor assembly in until you seat the Offset Ring within the HAMR Sleeve.

Place the Stepped Ring into the HAMR Cap so that the step is centered in the opening of the Cap.



Slide the offset ring onto the motor case with the concave side toward the Aft Closure. Press the Centering Sleeve over the Forward Closure of the motor. Be sure it is fully seated against the closure.



Screw the Cap and Stepped Ring assembly onto the HAMR Sleeve. Be sure the Stepped Ring is still centered in the Cap before snugging.

That's it!



www.publicmissiles.com