



Asphalt Kingdom

Parts Manual RBMGX and RBMGC



MAKING THE HARD PARTS EASIER!

Parts List

Part	Description	Part Number	Qty
Engine RBMGX	Honda Industrial Engine GX160	RB2000	1
Engine RBMGC	Honda Engine GC160	RB3000	1
Gearbox	Main Gearbox	RB3001	1
Clutch	Centrifugal Clutch	RB3002	1
Belt	Belt from Clutch to Gearbox Pulley	RB3003	1
Sheave	Pulley on Gearbox	RB3004	1
Shaft	Main Broom Shaft	RB3005	1
Gearbox Mount	Main Plate to Mount Gearbox and Tension Belt	RB3006	1
Shaft Washer	Washer on top of gearbox	RB3007	1
Belt Guard	Inner Guard	RB3008	1
Belt Guard	Outer Guard	RB3009	1
Broom	Main Broom	RB1002	1
Tires	Flat Free Tires	RB1003	2
Throttle Cable	Throttle Cable for Model# RBMGX and RBMGC	RB1004	1
Safety Pin	Safety Pin for Handle Arm adjustment	RB1006	2
Black Lever Handle	Lever Handle to tighten Handle Bars	RB1007	1
Wheel Cotter Key	Cotter Key to hold wheels in place	RB1008	2
Wheel Washer	Washer for holding wheel in place	RB1009	2
Handle Bar plug	Black plastic plug on Handle Bars	RB1010	2
Grips	Rubber Grips on Handle Bars	RB1011	2
Bolt	Main Brush Bolt to mount on Gearbox Shaft	RB1015	1
Nut	Nylock Nut (Main Brush Bolt)	RB1016	1
Bolt	Throttle Handle Pivot Bolt	RB1017	1
Nut	Nylock Nut (Pivot Bolt)	RB1018	1
Bolt	Handle Bar Cable Clamp Bolt	RB1019	1
Nut	Nylock Nut (Cable Clamp)	RB1020	1
Bolt	Broom Mount Plate Bolts	RB1021	4
Nut	Nylock Nut (Broom Mount Plate)	RB1022	4
Bolt	Gearbox Mounting Bolts	RB3010	8
Bolt	Main Shaft Bolt(Top of Gearbox)	RB3011	1
Nut	Gearbox Mounting Plate	RB3012	4
Bolt	Engine Mounting Bolts	RB3013	4
Nut	Engine Mounting Nuts	RB3014	4
Bolt	Outer Belt Guard Bolt	RB3015	4
Bolt	Inner Guard Bolt	RB3016	2
Cable Clamp	Clamp for Throttle Cable on Handle Bars	RB1023	1

Throttle Grip	Rubber Grip on Throttle Handle	RB1024	1
Tapered Bushing	Tapered Bushing for Broom Mount Plate to mount on Engine Shaft	RB1025	1
Main Frame	Orange Main Frame of unit	RB3017	1
Broom Plate	Plate used to Mount Broom to Gearbox Shaft	RB1027	1
Handle Arm	Main Black Arm from Frame to Bars	RB1028	1
Handle Bars	Chrome Handle Bars	RB1029	1
Throttle Handle	Handle Bar Throttle Lever	RB1030	1
Wheel Spacer	Spacers for Wheels between Frame and Wheels	RB1032	2
Wheel Shaft	Shaft that Wheels go on	RB1033	1



