


CANBUS WIRE HARNESS

Note:
This connector can be left
disconnected - it is unused



1. CONNECT TO H7 FEED FROM CAR
2. CONNECT TO CANBUS CANCELLER
3. CONNECT TO HID BALLAST

4. CONNECT TO 12v+ (plus) SOURCE OF BATTERY
5. CONNECT TO - (ground) OF BATTERY / CHASSIS
6. CONNECT HID BALLAST TO HID BULB CONNECTORS