
Instructions

DIS / AMP ADAPTER





- 1. CONNECT TO THE OUTPUT OF THE OEM BALLAST
- 2. CONNECT TO AMP CONNECTORS OF THE H1 HID BULB

