


## H4 HEADLIGHT H4 DIODE CABLES



1. CONNECT TO H4 FEED FROM CAR
2. CONNECT TO BALLAST
3. CONNECT TO AMP-D2S ADAPTER
4. CONNECT TO D2S BULBS
5. CONNECT TO SOLENOID CABLE OF THR PROJECTOR