



To set your Clam Trap pull open the two halves and hold apart with your forearms.



Then let the trap close gently whilst lining up the two trigger 'perch' halves. The faces of the wooden trigger should now take the pressure and hold your Clam Trap open.



If you find the trigger faces are slipping and are not holding the trap open then simply rotate one side 45 degrees until a good hold is made.



Visit our site