

Bridge Sink Mixer Tap

(handle design may vary)

INSTALLATION GUIDE & AFTERCARE INFORMATION



ENKI®

Instructions for KT046, KT056, KT057, KT058

WWW.HOUSEOFENKI.COM

Introduction

This owner's guide shows you how to install, maintain and generally get the most from your bridge sink mixer tap. Please retain this manual after installation for future reference and maintenance. **We recommend installation by a qualified plumber only. Product must be installed in compliance with relevant Water Regulations and Byelaws.**



IMPORTANT

Flush system prior to installation

Check for leaks after installation

Hot supply must be on the left

Isolating valves must be fitted to allow future servicing of the fitting

Product Specification

Minimum pressure 0.2 bar

Maximum pressure 5.0 bar

Equal (balanced) inlet supply pressures are recommended for optimum performance

Installation

1. Identify and check all the parts
2. Fit the mixer to the sink or worktop using the washers and backnuts provided.
3. Fully open both valves, letting them run for a few minutes to flush out the system.
4. Check all joints and connections for leaks.

Aftercare

When installing or using tools, extra care must be taken to avoid damaging the finish or the fitting. To maintain the appearance of this fitting, please ensure it is cleaned regularly using a clean soft damp cloth only. Abrasive cleaners or detergents must not be used as they may cause surface deterioration.

Maintenance

If the taps begin to drip:

1. Turn off the water supply.
2. Remove fitting handle, decorative collar and valve.
3. Carefully clean seating and rubber washer, descale valve.
4. Replace valve, decorative collar and handle.
5. Turn the water supply back on.

Replacement valves part number: TA039

GUARANTEE

This product is manufactured to high standards and guarantee covers any defect in manufacture. Proof of purchase is required. Please have proof of purchase readily available when contacting us.

For full product guarantee details, please visit: <https://houseofenki.com/guarantee/>

IMD Trading Ltd. T/A HOUSE OF ENKI

Unit 2, Square Deal Units
5 West Road
Harlow
Essex
CM20 2BQ
United Kingdom

WWW.HOUSEOFENKI.COM

Enquiries: 0800 086 8793
Trade: sales@houseofenki.com
Customer care: support@houseofenki.com

