

COMPATIBLE BALLAST LIST

LR34194

COMPATIBLE BALLASTS*

| BRAND | BALLAST DESCRIPTION | | | 1 LAMP LOAD | | 2 LAMP LOAD | | 3 LAMP LOAD | | 4 LAMP LOAD | |
|----------------|-----------------------|--------------|------------|---------------|------|---------------|------|---------------|------|---------------|------|
| | PART NUMBER | START METHOD | # OF LAMPS | INPUT VOLTAGE | | INPUT VOLTAGE | | INPUT VOLTAGE | | INPUT VOLTAGE | |
| | | | | 120V | 277V | 120V | 277V | 120V | 277V | 120V | 277V |
| STANDARD | E232PI120L | IS | 2 | • | - | • | - | - | - | - | - |
| | E232T8IS120/N/AS | IS | 2 | • | - | • | - | - | - | - | - |
| | E432T8IS120/H | IS | 4 | - | - | - | - | X | - | • | - |
| | E432T8IS120/L/AS/BULK | IS | 4 | - | - | - | - | • | - | • | - |
| | E432T8IS120/N/AS/BULK | IS | 4 | - | - | - | - | • | - | • | - |
| ADVANCE | ACT4P32ISUNV | IS | 4 | - | - | - | - | • | • | • | • |
| | ICN-2P32-N | IS | 2 | X | X | • | • | - | - | - | - |
| | ICN-2P32-SC | IS | 2 | • | • | • | • | - | - | - | - |
| | ICN-2S40-N | IS | 2 | • | • | • | • | - | - | - | - |
| | ICN-4P32-N | IS | 4 | - | - | - | - | • | • | • | • |
| | ICN-4P32-SC | IS | 4 | - | - | - | - | • | • | • | • |
| | ICN-1P32-N | IS | 1 | • | • | - | - | - | - | - | - |
| | IOPA-1P32-N | IS | 1 | • | • | - | - | - | - | - | - |
| | IOPA-2P32-N | IS | 2 | X | X | • | • | - | - | - | - |
| | IOPA-1P32-LW-N | IS | 1 | X | X | - | - | - | - | - | - |
| | IOPA-2P32-LW-N | IS | 2 | X | X | • | • | - | - | - | - |
| | IOPA-4P32-LW-N | IS | 4 | - | - | - | - | • | • | • | • |
| | IOPS-1P32-N | IS | 1 | • | • | - | - | - | - | - | - |
| | IOP-4P32-LW-N | IS | 4 | • | • | • | • | • | • | • | • |
| | RCN-2S32-SC | PS | 2 | - | - | • | - | - | - | - | - |
| | REZ-2S32-SC | PS | 2 | - | - | • | - | - | - | - | - |
| | REL-2P32-SC | IS | 2 | • | - | • | - | - | - | - | - |
| REL-4P32-RH-TP | IS | 4 | - | - | - | - | • | • | • | • | |
| RELB-2S40-N | RS | 2 | • | - | • | - | - | - | - | - | |
| ESPEN | VE232MVHIP | IS | 2 | • | • | • | • | - | - | - | - |
| | VE232MVHIPE | IS | 2 | • | • | • | • | - | - | - | - |
| | VE232MVHIPHE | IS | 2 | X | X | • | • | - | - | - | - |
| | VE232MVHIPL | IS | 2 | • | • | • | • | - | - | - | - |
| | VE432MVHIP | IS | 4 | - | - | - | - | • | • | • | • |
| | VE432MVHIPE | IS | 4 | - | - | - | - | • | • | • | • |
| | VE432MVHIPHE | IS | 4 | - | - | - | - | • | • | • | • |
| FULHAM | NPY-120-232-LT8 | PS | 2 | • | - | • | - | - | - | - | - |
| | NPY-120-432-T8-B | IS | 4 | - | - | - | - | • | - | • | - |
| | NPY-120-432-T8-S | IS | 4 | - | - | - | - | • | - | • | - |
| | WHCG3-120-T8-IS | IS | 3 | - | - | • | - | • | - | - | - |
| | WHCG5-120-T12-RS | RS | 2 | • | - | • | - | - | - | - | - |
| | WHL-120-L | IS | 2 | • | - | • | - | - | - | - | - |
| | WH5-120-L | IS | 2 | - | - | X | - | - | - | - | - |
| FUSION | FB232MVE | IS | 2 | • | • | • | - | - | - | - | - |
| | FB232MVE-HE | IS | 2 | • | • | • | - | - | - | - | - |
| | FB232MVE-LHE | IS | 2 | • | - | • | - | - | - | - | - |
| | FB232MVE-PPS-HE | PS | 2 | • | • | • | - | - | - | - | - |
| | FB332MVE | IS | 3 | - | - | • | • | • | • | - | - |

| BALLAST DESCRIPTION | | | | 1 LAMP LOAD | | 2 LAMP LOAD | | 3 LAMP LOAD | | 4 LAMP LOAD | |
|---------------------|-----------------------|--------------|------------|---------------|------|---------------|------|---------------|------|---------------|------|
| BRAND | PART NUMBER | START METHOD | # OF LAMPS | INPUT VOLTAGE | | INPUT VOLTAGE | | INPUT VOLTAGE | | INPUT VOLTAGE | |
| | | | | 120V | 277V | 120V | 277V | 120V | 277V | 120V | 277V |
| | FB432MVE | IS | 4 | - | - | - | - | . | . | . | . |
| | FB432MVE-HE | IS | 4 | - | - | - | - | . | . | . | . |
| | FB432MVE-PPS-HE | PS | 4 | - | - | - | - | . | . | . | . |
| GE | GE 232-120RES-DIYB | IS | 2 | . | - | . | - | - | - | - | - |
| | GE 232-120-PS-N | PS | 2 | . | - | . | - | - | - | - | - |
| | GE232MAX-G-N | IS | 2 | . | . | . | . | - | - | - | - |
| | GE232MAX-N | IS | 2 | . | . | . | . | - | - | - | - |
| | GE232-MVPS-L | PS | 2 | . | . | . | . | - | - | - | - |
| | GE232-MV-N | IS | 2 | . | . | . | . | - | - | - | - |
| | GE-232-MVPS-H | PS | 2 | x | x | . | . | - | - | - | - |
| | GE332MAX90-V60 | IS | 3 | - | - | x | x | . | . | - | - |
| | GE332MV-N-DIY | IS | 3 | - | - | . | . | . | . | - | - |
| | GE432MAX-H-42T | IS | 2 | - | - | - | - | . | . | . | . |
| | GH2P59ISUNV | IS | 2 | x | x | . | . | - | - | - | - |
| GREEN HILL | GH4P32ISUNV | IS | 4 | - | - | - | - | . | . | . | . |
| HALCO | EP232IS/H/MV/HE | IS | 2 | x | x | . | . | - | - | - | - |
| | EP332IS/L/MV/HE | IS | 3 | - | - | . | . | . | . | - | - |
| | EP332IS/MV/MC | IS | 3 | - | - | . | . | . | . | - | - |
| | EP432IS/L/MV/HE | IS | 4 | - | - | - | - | . | . | . | . |
| | EP432IS/MV/MC | IS | 4 | - | - | - | - | . | . | . | . |
| KEYSTONE | KTEB-232-UV-PS-VDIM | PS | 2 | - | - | . | . | - | - | - | - |
| OSRAM | QHE 2x32T8/UNV DIM-TC | PS | 2 | - | - | . | . | - | - | - | - |
| | QHE 4*32T8/UNV PSN-SC | PS | 4 | . | . | . | . | . | . | . | . |
| HOWARD | EP4/32IS/MV/MC/HE | IS | 4 | . | - | . | - | . | . | . | . |
| | EPL3/32IS/MV/SC/HE | IS | 3 | . | . | . | . | . | . | - | - |

*The presence of a ballast on this chart is not a guarantee of the compatibility of the bulb in any particular installation. Absence of a ballast on this chart does not imply incompatibility. Please reference the ballast manufacturer's instructions for installation and further information.

IS= INSTANT START
 PS= PROGRAMMED RAPID START
 RS= RAPID START

. = YES
 - = N/A
 x = NO