

## CCT & WATTAGE SELECTABLE LED HID LIGHT LR41605, LR41607, LR41609

**CAUTION - DO NOT** use electric generator to test the LED lamp. Please avoid using the LED fixture in environments where there is smoke, sulfur and corrosive substances. If used in such environments, make sure the LED fixture is well protected by an enclosed lampshade with dimensions no less than the size noted on the table below, and that the material is either glass or semi-glass, semi-metallic. Surface of the lampshade shall not have any covering that prevents heat dissipation.

Power(W)	36	63	120
Volume (CM)	38*20*20	42*23*23	44*26*26

WARNING - THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS. ADDED WEIGHT OF THE DEVICE MAY CAUSE INSTABILITY OF A FREE STANDING PORTABLE LUMINAIRE. USE ONLY WITH A PORTABLE LAMP THAT IS PROVIDED WITH A SHADE.

**AVERTISSEMENT -** NE CONVIENT PAS AUX SORTIES DE SECOURS. LE DISPOSITIF CONSTITUE UN POIDS SUPPLÉMENTAIRE CE QUI PEUT CAUSER L'INSTABILITÉ D'UN LUMINAIRE PORTATIF AUTONOME UTILISER UNIQUEMENT AVEC UNE LAMPE DE TABLE DOTÉE D'UN ABAT-JOUR


## **INSTALLATION INSTRUCTIONS**


WARNING: MAKE SURE THE POWER IS OFF BEFORE ATTEMPTING INSTALLATION.

- 1. TURN OFF POWER SWITCH
- 2. Screw on HID light

**NOTE:** MAKE SURE TO TAKE OFF THE BALLAST BEFORE INSTALLING THE HID LIGHT, OTHERWISE THE BALLAST WILL PRODUCE THE RESONANCE OF HIGHT VOLTAGE AND WILL MAKE LIGHT BREAKDOWN.

- 3. If a safety chain is provided, hook it onto the safety hook on the light. FIG. 1
- 4. Lamp CCT and dimming can be adjusted after removing the top plastic cover with the key provided in the box. FIG. 2
- 5. Turn on the power





732-882-1500 ♦ luxrite.com