

User Manual

Urbane

Features

- Date Display
- Quartz Movement
- Stainless Steel Case



How to Set Date and Time

- 1. Pull out the crown to position C.
- 2. Turn crown either way to correct time.
- 3. Adjust your correct time & again push the crown to position B.
- 4. Turn crown either way to correct date.
- 5. Set your correct date.
- 6. Push the crown to the position A (Normal).



• How to Open / Close Buckle

- 1. Find the small push-button on the side of the clasp.
- 2. Gently press the push-button.

- 3. As you press the button, you'll notice the clasp opening.
- To close the watch band, position the two ends together and gently press it.



