

R20/22/24

Openers Equipped with Learn Code Button (1995 to present)

1. Press then release the "Learn Code" button on the OPENER hanging in your garage (LED will blink rapidly)
2. Press then release the button you wish to program on the remote transmitter (LED will stop blinking)
3. Press then release the same button on the remote transmitter (the LED will go out)
4. Press the same button on the remote one more time. The garage door will open indicating successful programming.

**Repeat the steps above if you wish to program multiple remotes (or a multi-button remote to multiple doors). If a remote loses it's "program" repeat the steps above.

For Openers Equipped with Program/Set Button (2010 to present)

1. Locate the Program/Set Button and the indicator LED on the OPENER hanging in your garage.
2. Hold the Program/Set Button until the LED turns blue and then release. The LED will then blink purple.

3. Press then release the button you wish to program on the remote transmitter (the LED will stop blinking)
4. Press then release the same button on the remote transmitter (LEDs will turn off after blinking blue)
5. Press the same button on the remote one more time. The garage door will open indicating successful programming.
6. * *Repeat the steps above if you wish to program multiple remotes (or a multi-button remote to multiple doors). If a remote loses it's "program" repeat the steps above.

WARNING

In order to prevent possible **SERIOUS INJURY** or **DEATH** from a moving gate or garage door:

- keep remote controls out of the reach of children.
- Only use the remote control when the gate/garage door can be seen clearly, is properly adjusted, and there are no obstructions to door travel.
- Keep the gate/garage door in sight until it is completely closed. Do not allow anyone to cross paths with the gate/garage door while moving or operating the remote control.