



HROEENOI

TO CREATE ENJOYABLE AUDIO

WRHW05



User Manual

Table Of Contents

| | |
|-------------------------|---|
| Specifications | 1 |
| Connection Instructions | 2 |
| In-line Controller | 3 |
| Troubleshooting | 4 |
| Customer Support | 6 |

Specifications

| | |
|-------------------------|--------------------------------|
| Headphone Type | Wired Headset |
| Headphone Form Factor | On Ear Headphones |
| Microphone Size | $\Phi 4.0 \times 1.5\text{mm}$ |
| Microphone Sensitivity | $-42 \pm 3\text{dB}$ |
| Directivity | Unidirectional Microphone |
| Microphone Impedance | $2.2\text{K}\Omega$ |
| Cable Length | 6.5ft (2.0m) |
| Loudspeaker Diameter | $\Phi 27\text{mm}$ |
| Loudspeaker Impedance | $32\Omega \pm 15\%$ |
| Frequency Response | 20Hz-20KHz |
| Loudspeaker Sensitivity | $95 \pm 3\text{dB}$ |
| Input Power | 15mW |
| Input Interface | 3.5mm |

Connection Instructions

Phone/Tablet/PC Setup

1. From the Start menu, select Settings>Devices>Audio Devices>Output to Headset>Select All Audio

Please Note:


1. For iPhone 7...or Newer iPhone, Original Lightning to 3.5mm Adapter is required. (Must be supplied by the Apple store, otherwise the headset will not work).
2. If the sound is low, it is recommend to position the microphone close to your mouth (0.5 inches).



In-line Controller

Mute function explanation

1. During a call, please push down the "③" button, the mute function will be activated. You can still hear the other party's voice, but the other party will not hear your voice.
2. To turn off the mute function, just push the "③" button upward.



Volume control

1. To increase the volume: please slide the scroll wheel in the "+" direction.
2. To decrease the volume: please slide the wheel in the "-" direction.

Troubleshooting

The headset does not work:

- Confirm that the headset is plugged firmly into the Audio Control Unit.
- Adjust the headset volume on the volume control.
- Make sure the headset is not muted, check the connection between the headset and the device interface, connect directly to the device do not use an adapter cable.
- In your application and operating system, check the volume and microphone settings.

Correct Disposal of This Product

(Waste Electrical & Electronic Equipment)

- This marking shown on the product or its literature indicate that it should not be disposed with other household wastes at the end of its working life.
- To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
- Household user should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recycling.
- Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Warranty Service

12 months warranty

Lifetime customer support

Customer Support

After-sale E-mail: hroeenoi@gmail.com

Official Website: <https://www.hroeenolive.com>