


## Set Up Instructions

# OneFabric 7.5ft Straight Tabletop Display


**Step 1:** Carefully remove frame and graphic from nylon bag.



**Step 2:** Ensure “adjustable feet” of frame are on the floor. Pull up display into upright position.



**Step 3:** Lock all hooks between front and back hubs.



**Step 4:** If supplied with fabric end caps, wrap Velcro fabric edges around all end cap brackets on both sides. Pull past edge if needed to make taut.



### WARNING BEFORE COLLAPSING THE FRAME:

Step 1: Both graphic end caps must be detached from end cap brackets before collapsing frame.


Step 2: **To avoid damage to the frame**, all hooks must be unhooked and separated from each other.

Once this is done the frame should begin to collapse under its own weight without much effort.



### LIGHTS:


(OPTIONAL) Attach lights to top of frame by sliding the plastic “x block” under the rear pole and over the front pole.




## Set Up Instructions

# OneFabric Graphic Installation


**Step 1:** Assemble frame and lay flat on its back. Remove existing graphic.




**Step 2:** Starting at one corner, attach Velcro on the graphic to Velcro on the frame. Note: Velcro on the graphic should extend approx. 1/4" beyond Velcro on the frame (it should not be flush).



**Step 3:** Working in a continuous direction around the frame, attach the rest of the graphic. If supplied with end caps, attach end cap Velcro to end cap brackets on both sides.



**Step 4:** If needed, adjust Velcro for taut fit. Complete.



### WARNING BEFORE COLLAPSING THE FRAME:

Step 1: Both graphic end caps must be detached from end cap brackets before collapsing frame.

Step 2: **To avoid damage to the frame**, all hooks must be unhooked and separated from each other.

Once this is done the frame should begin to collapse under its own weight without much effort.

