


C L Chinese 2 French R =

の の好、根拠所以を称! Hello, nice to meet you! <





Calling answering: Tap once on any earbud

Reject incoming call: Long press any earbud for 2 seconds

(III) Voice assistants ("Hey Siri or OK Google")

Makephonecalls

Listen to music

Play/Pause: Tap once on any earbud

Previous song: Double-tap left earbud

Next song: Double-tap right earbud

Charge the earbuds for 30 minutes and take the earbuds out of the charging case, it will turn on automatically.

Unable to start

Earbuds cannot pair

the earbuds back to charging case. Please open the charging case and reconnect with your mobile device.

Only one earbud is working/Both earbuds not working simultaneously

Go to the mobile's Bluetooth menu and forget/disconnect the WAS-M9 and put

Cannot connect to mobile device

Turn off the earbuds by putting them in charging case. Turn off mobile device Bluetooth function and turn it on again. Please open the charging case and reconnect with your mobile device.

Start the voice service: Triple-tap either earbud The earbuds can't be charged Leave voice service: Triple-tap either earbud

Make sure earbuds are placed in case with right orientation, gently press them, clean the charging pins.

Earbuds Charging

When put earphones into charging case and close the cover, earbuds starts to

becharging. When the earbuds are fully charged, Earbuds White light will be displayed for 10 seconds and then turn off. Charging Case

During charging, the white light flashes; once fully charged, the white light

remains on. When opening or closing the lid, the green light illuminates for fou seconds and then turns off. 1) Do not use unofficially recommended of

or other dangers.

- 2) Do not deliberately drop, burn, penetra product damage.
- 3) Do not expose to high temperatures or around heating equipment such as microwaves or ovens.

with your mobile device.

- 4) Use the device within the range of 0°C ~ 35°C and store within the range of Go to the mobile's Bluetooth menu and forget/disconnect the WAS-M9 and put
 - -20°C ~ 45°C. If the temperature is too high or too low, it will cause the device to
 - 5) We are not responsible for quality issues, product failures, and safety accidents caused by the use of unofficial approved accessories.

11. After-sales Service And Support

Order Number				
Return/Change	□ Return □ Change	Reason		
Member ID				
Phone Number				

After confirmation, please fill in this form in detail, and return it with the produc

Please read the following safety and warning information before

the earbuds back to charging case. Please open the charging case and reconnect

_				Hazardous Substance							
d charging methods to avoid fire, explosion,		Component	Pb	Hg	Cd	Cr/VI	PBB				
trate, squeeze or immerse in liquid to avoid			Shell	0	0	0	0	0			
	ı		1								

The form is compiled according to SJ/T11364

 Indicates that this hazardous substance contained in all homogeneous materials of this part is below the limit requirement in GB/T 26572.

12. Harmful Substances

 Indicates that this hazardous substance contained in at least one of the homogeneous materials of this part is above the limit requirement in GB/T 26572.



nmental protection service life

This product meets RoHS environmental protection requirements. it vnot affect the health of users under normal use. (At present, there is no mature technology in the world to replace or reduce lead content in electronic ceramics, optical glass, steel and copper alloys.)

If you need to return or change the goods, please contact customer service