

Mini Noah's Ark by Scrollsaw.com



Thank you for supporting Scrollsaw.com which is a family-owned American small business!

Enjoy this FREE pattern and spread the joy, love, and skill of scrolling!

Use the code "PatternClub" for 10% OFF on the web.





Copyright 2009. All Rights Reserved. SRX Enterprises, LLC. omegacom@gmx.com / berrybasketplans@gmail.com


#P307A - Assembly Instructions


- 1. Select your material from a variety of hardwoods or solid core plywood.
- Measure each pattern piece and cut the work pieces to size accordingly. Sand as necessary.
- Make all pattern pieces by adhering the paper patterns to the work pieces with a repositionable spray adhesive. Cut the outer shapes and any interior designs. And drill where indicated.
- Remove all paper patterns. Sand where needed. The edges can be rounded by sanding or using a small roundover router bit if desired.
- 5. Assemble by first attaching the Ends and Deck to one Side with glue and brads. Then attach the remaining Side. Next attach the Cabin and Roof. Attach the Support Block and finish as desired. Optional: cut the number of waves desired.


Roof (E)

Stock: 1/8" - 1/4", cut 2

#P307A - Toy Noah's Ark			
Description	Item	Qty	Size
Side	Α	2	3/8°T x 3 1/4"W x 6 1/8°L
Deck	В	1	1/4"T x 2"W x 4"L
End	С	2	1/4"T x 1 3/8"W x 2"L
Cabin	D	1	3/4°T x 1 1/4"W x 2 5/8"L
Roof	Е	2	1/8 - 1/4"T x 1"W x 3 1/8"L
Support Block	F	1	3/4°T x 3/4"W x 2°L
Wave	G	2-4	3/8" - 3/4"T x 1 1/4"W x 6 3/4"L











#P307A

Copyright 2009. All Rights Reserved. SRX Enterprises, LLC. omegacom@gmx.com / berrybasketplans@gmail.com