

HugglePod® Lite

Mesh Hanging Chair by HearthSong®

Safety and Assembly Instructions

Includes:

- ▷ 1 Hanging chair (55"H x 28" diam.)
- ▷ 1 Inflatable cushion
- ▷ 1 Stainless steel carabiner
- ▷ 1 Vinyl repair patch kit


**Assembly video available at
HearthSong.com, search 733657**

Assembly:

1. Unpack the inflatable cushion and flatten it out.
2. Insert uninflated cushion into the zippered pocket at the back of the hanging chair, leaving the valve exposed.
3. Slowly inflate the cushion. See detailed directions on how to use Two-Stage valves.
4. Once inflated, press the closed valve into the cushion so it is flush with the surface.

Using Two-Stage Quick-Release

Air Valves: This toy is equipped with two-stage quick-release valves which allow fast inflation and deflation.



Inflation:

- ▷ Hand, electric, or foot pump recommended and sold separately at HearthSong.com. Please do not overinflate.
- ▷ Do not inflate with an air compressor or any high-pressure hose at a filling station.



Installation:

1. We recommend hanging your HugglePod Lite from a stand, sold separately.
2. Indoor Installation: If hanging the HugglePod Lite from a ceiling, the suspension device must be installed by a professional. For outdoor installation, we recommend use HearthSong's Multi-Use Hanging Strap (sold separately). In both cases, suspend the seat no more than 18" from the ground when occupied. Ideally, suspend HugglePod Lite over a soft surface such as grass, sand, wood chips, or carpet.

Care: Spot clean only.

Vinyl Plastic Repair:

A vinyl plastic repair kit is included with your inflatable. TO USE:

- ▷ Thoroughly clean the damaged area and allow surface to dry for a minimum of 10 minutes.
- ▷ Cut a patch large enough to completely cover the hole or puncture.
- ▷ Remove the paper backing from the patch and press patch firmly over affected area.
- ▷ Do not inflate for 20 minutes.

Safety Guidelines:

Owners shall be responsible for maintaining the legibility of any warning labels. Following the safety guidelines and warnings below will reduce the likelihood of serious or fatal injury.

- ▷ This product is not suitable for children below the age of four years. Do not place a baby in the HugglePod. The cushion poses a risk of suffocation.
- ▷ HugglePods have a limited lifespan. Distinct changes in color might indicate wear and tear. In addition, fabrics and straps are subject to wear and tear and may become brittle. If the color of the strap has become pale, frays easily, or gives off a powdery residue when rubbed between the fingers, we recommend you replace your HugglePod. Exposure to heavy loads, direct sunlight, damp weather conditions, and frequent cleaning will shorten their lifespan.
- ▷ We recommend no more than one child on the HugglePod at one time, with a maximum carrying capacity of 175 lbs. Inspect the HugglePod prior to each use and dispose of it if the full carrying capacity is no longer warranted.
- ▷ A fall onto a hard surface can result in serious injury to the equipment user.
- ▷ Adult supervision is required.
- ▷ Make sure that the product is not misused as a swing, spinner, gymnastics equipment, or climbing frame. Be aware that there is no safety belt that could prevent a child from falling out of the HugglePod.
- ▷ Adults should verify that the hanging ropes are secured and cannot be looped back on the HugglePod.

Caution When Using the Cushion:

- ▷ This inflatable must be at room temperature before it is inflated. Otherwise it is at risk of temperature shock and can become defective.
- ▷ Do not drag this inflatable over sharp objects or surfaces.
- ▷ Avoid contact with hot or sharp objects.
- ▷ THIS IS NOT A LIFE-SAVING DEVICE.