

#3222

Timber Baby Bed Rail



Fits up to King size: Max 185cm (73") 95cm Wide / 50cm Tall (37.4" Wide / 19.68" Tall)

IMPORTANT! READ AND FOLLOW THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE.

TABLE OF CONTENTS

SAFETY INFORMATION	
General	03
Maintenance	03
Warnings	04-05
WHAT'S IN THE BOX	
Parts	06
INSTALLATION	
Frame Assembly	07-08
Positioning the Bed Rail	09
Positioning the Bed Rail - Minimum Distance	10
OPERATION	
Cleaning Instructions	11
SUPPORT	
Warranty Certificate	12
Warranty Card	13
After Sales Support	13

SAFETY INFORMATION

GENERAL

Read this instruction manual carefully and keep it in a safe place for future reference.

The correct use and maintenance of this product is essential.

MAINTENANCE

Regularly check that the product is functioning correctly. Tighten and adjust to ensure secure smooth operation. Inspect all components regularly and stop using if any component is damaged or missing.

Refer to page 11 for cleaning instructions.



Adult assembly required.

Carefully read all instructions before assembly and use of the product.

Dispose of all packaging materials carefully after assembly.

Not suitable for use of children under the age of 18 months or when the child is over the age of 5 years.

Only use the Bed Rail when the child is able to climb in and out of the bed unaided.

The Bed Rail should not be used as a substitute for a cot as it does not provide the same level of safety as a cot.

The Bed Rail should be periodically checked for its general condition with particular reference to the security of any locking mechanism and / or hinges that are used on the product.

Intended for use with beds sized 1400 - 1900mm (55"- 75") in length, up to 1850mm (73") in width and with mattress thickness of 130 - 270mm (5"- 10.6").

Intended for use with single, double, queen size, king size beds or children's mattress only.



Any additional or replacement parts should be obtained from After Sales Support.

The Bed Rail should not be used on a sleeping surface that is more than 600mm (23.6") from the floor.

To prevent risk of strangulation, it is essential to ensure that when the Bed Rail is fitted into position, there is a gap of at least 250mm (10") between each end of the bed and the corresponding end of the Bed Rail.


Care should be taken in unpacking and assembly.

Fit the bed rail so that its side, when placed in the fitted position, touches the side of the mattress.

The Bed Rail should not be used unless securely fitted between the bed and the mattress.

Once fitted into place, the Bed Rail should be checked to ensure that it is properly fitted and secure.

PARTS



1 x Bed Rail Frame



2 x Connector Rods

1 x Support Bar (Large Holes through all the way)

1 x End Support Bar (Large Holes + Small Holes)



2 x Small Bolts




2 x Large Bolts




1 x Allen Key

STEP 1. FRAME ASSEMBLY

1. Insert both Connector Rods into the bottom holes of the Bed Rail Frame.




2. Slide + Twist Connector Rods up into position.



STEP 1. FRAME ASSEMBLY - CONTINUED

4. Slide Support Bar onto the two Connector Rods. Ensure it is placed as low as possible.



5. Slide on End Support Bar onto the two Connector Rods.

Insert into the larger hole side.


6. Locate the screw holes. Using the Allen Key insert 2x Large Bolts.

Secure until firm.



STEP 2. POSITIONING BED RAIL

- 1. Remove mattress.
- **2.** Place Bed Rail evenly spaced on the bed frame.
- **3.** Adjust the support board as required. Ensure it is evenly spaced.
- 4. Replace the mattress.



WARNING **A**

Ensure the mattress is heavy enough to keep the Bed Rail in place.

If the Bed Rail can tip, it is advised not to continue using as it may not be safe.

Further support may be required such as screwing the bed rail into the bed frame.



Suitable for single, double, queen, king or children's mattress.

Maximum 185cm (73") Width.


STEP 2. POSITIONING BED RAIL - CONTINUED

WARNING (L)

To prevent the risk of strangulation, ensure that when the Bed Rail is fitted into position, there is a gap of at least 250mm (10") between each end of the bed and the corresponding end of the Bed Rail.



CLEANING INSTRUCTIONS



Clean using warm soapy water, or a damp cloth and dry thoroughly after cleaning. Do not use abrasive cleaners or bleach.

WARRANTY CERTIFICATE

Congratulations! You have made an excellent choice of this quality product. Our commitment to quality also includes our service. Should you, contrary to expectations, experience defects due to manufacturing faults, we will provide you with a warranty against defects as follows:

WARRANTY

Our goods come with guarantees that cannot be excluded under the Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Simply contact us at www.permachildsafety.com/contact within 24 months of purchase together with details of the failure and original purchase receipt.

PROOF OF PURCHASE

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket, tax invoice or receipt as the best proof of purchase and date on which the purchase was made.

EXTENT OF WARRANTY

This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not cover consumable items.

NORMAL WEAR AND TEAR

This warranty does not cover normal wear and tear to the products or parts.

EXCLUSIONS

This warranty does not cover:

- Any defects caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has not been installed, operated or maintained in accordance with the manufacturer's operating
 instructions provided with the product.
- Any product that has been used for purposes other than domestic use.

TO MAKE A CLAIM

If a defect in the goods appears within 24 months / 2 years, you are entitled to claim a warranty.

Please contact after sales support via the link below:

permachildsafety.com/pages/warranty-claim-refund

Please ensure that you have a copy of proof of purchase so that we are able to respond as quickly and efficiently as possible.

WARRANTY CARD

We recommend that you keep a copy of your receipt, showing the date of purchase, with this warranty certificate and keep for your reference. In the event of a product fault, please contact after sales support. Ensure that you include the product details (as shown on this card) so that we are able to respond as quickly and efficiently as possible.



Scan the QR Code to submit Warranty Claim or visit: permachildsafety.com/pages/warranty-claim-refund







Scan the QR code for Live Chat Support or visit: permachildsafety.com/contact-us



f Perma Child Safety

